

A  
B  
C

# SECTION **WW**

## WIPER & WASHER

### CONTENTS

<p><b>BASIC INSPECTION</b> ..... 4</p> <p><b>DIAGNOSIS AND REPAIR WORKFLOW</b> ..... 4</p> <p style="padding-left: 20px;">Work Flow .....4</p> <p><b>SYSTEM DESCRIPTION</b> ..... 6</p> <p><b>FRONT WIPER AND WASHER SYSTEM</b> ..... 6</p> <p style="padding-left: 20px;">System Diagram .....6</p> <p style="padding-left: 20px;">System Description .....6</p> <p style="padding-left: 20px;">Component Parts Location .....9</p> <p style="padding-left: 20px;">Component Description .....9</p> <p><b>REAR WIPER AND WASHER SYSTEM</b> .....11</p> <p style="padding-left: 20px;">System Diagram ..... 11</p> <p style="padding-left: 20px;">System Description ..... 11</p> <p style="padding-left: 20px;">Component Parts Location ..... 13</p> <p style="padding-left: 20px;">Component Description ..... 14</p> <p><b>HEADLAMP WASHER SYSTEM</b> .....15</p> <p><b>FOR EUROPE</b> ..... 15</p> <p style="padding-left: 20px;">FOR EUROPE : System Diagram ..... 15</p> <p style="padding-left: 20px;">FOR EUROPE : System Description ..... 15</p> <p style="padding-left: 20px;">FOR EUROPE : Component Parts Location ..... 16</p> <p style="padding-left: 20px;">FOR EUROPE : Component Description ..... 16</p> <p><b>FOR RUSSIA</b> ..... 16</p> <p style="padding-left: 20px;">FOR RUSSIA : System Diagram ..... 17</p> <p style="padding-left: 20px;">FOR RUSSIA : System Description ..... 17</p> <p style="padding-left: 20px;">FOR RUSSIA : Component Parts Location ..... 18</p> <p style="padding-left: 20px;">FOR RUSSIA : Component Description ..... 18</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> .....19</p> <p><b>COMMON ITEM</b> ..... 19</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) ..... 19</p> <p><b>WIPER</b> .....20</p> <p style="padding-left: 20px;">WIPER : CONSULT-III Function (BCM - WIPER)...20</p> <p><b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....22</p>	<p style="padding-left: 20px;">Diagnosis Description .....22</p> <p style="padding-left: 20px;">CONSULT-III Function (IPDM E/R) .....24</p> <p><b>DTC/CIRCUIT DIAGNOSIS</b> .....27</p> <p><b>WIPER AND WASHER FUSE</b> .....27</p> <p style="padding-left: 20px;">Diagnosis Procedure .....27</p> <p><b>FRONT WIPER MOTOR LO CIRCUIT</b> .....28</p> <p style="padding-left: 20px;">Component Function Check .....28</p> <p style="padding-left: 20px;">Diagnosis Procedure .....28</p> <p><b>FRONT WIPER MOTOR HI CIRCUIT</b> .....30</p> <p style="padding-left: 20px;">Component Function Check .....30</p> <p style="padding-left: 20px;">Diagnosis Procedure .....30</p> <p><b>FRONT WIPER AUTO STOP SIGNAL CIRCUIT</b> .....32</p> <p style="padding-left: 20px;">Component Function Check .....32</p> <p style="padding-left: 20px;">Diagnosis Procedure .....32</p> <p><b>FRONT WIPER MOTOR GROUND CIRCUIT</b> ...34</p> <p style="padding-left: 20px;">Diagnosis Procedure .....34</p> <p><b>WASHER SWITCH</b> .....35</p> <p style="padding-left: 20px;">Description .....35</p> <p style="padding-left: 20px;">Component Inspection .....35</p> <p><b>LIGHT &amp; RAIN SENSOR</b> .....36</p> <p style="padding-left: 20px;">Description .....36</p> <p style="padding-left: 20px;">Component Function Check .....36</p> <p style="padding-left: 20px;">Diagnosis Procedure .....36</p> <p><b>REAR WIPER MOTOR CIRCUIT</b> .....38</p> <p style="padding-left: 20px;">Component Function Check .....38</p> <p style="padding-left: 20px;">Diagnosis Procedure .....38</p> <p><b>REAR WIPER AUTO STOP SIGNAL CIRCUIT</b> .....40</p> <p style="padding-left: 20px;">Component Function Check .....40</p> <p style="padding-left: 20px;">Diagnosis Procedure .....40</p> <p><b>HEADLAMP WASHER RELAY</b> .....42</p>
---	--

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW

Component Inspection .....	42	<b>FOR EUROPE .....</b>	<b>113</b>
<b>HEADLAMP WASHER SWITCH .....</b>	<b>43</b>	FOR EUROPE : Symptom Table .....	113
Description .....	43	<b>FOR RUSSIA .....</b>	<b>115</b>
Component Function Check .....	43	FOR RUSSIA : Symptom Table .....	115
Diagnosis Procedure .....	43	<b>NORMAL OPERATING CONDITION .....</b>	<b>118</b>
<b>HEADLAMP WASHER CIRCUIT .....</b>	<b>45</b>	Description .....	118
Component Function Check .....	45	<b>FRONT WIPER DOES NOT OPERATE .....</b>	<b>119</b>
Diagnosis Procedure .....	45	Description .....	119
<b>FRONT WIPER AND WASHER SYSTEM .....</b>	<b>48</b>	Diagnosis Procedure .....	119
<b>LHD .....</b>	<b>48</b>	<b>HEADLAMP WASHER DOES NOT OPER-</b>	<b>ATE .....</b>
LHD : Wiring Diagram .....	48	<b>FOR RUSSIA .....</b>	<b>121</b>
<b>RHD .....</b>	<b>48</b>	FOR RUSSIA : Description .....	121
RHD : Wiring Diagram .....	49	FOR RUSSIA : Diagnosis Procedure .....	121
<b>REAR WIPER AND WASHER SYSTEM .....</b>	<b>50</b>	<b>PRECAUTION .....</b>	<b>122</b>
<b>LHD .....</b>	<b>50</b>	<b>PRECAUTIONS .....</b>	<b>122</b>
LHD : Wiring Diagram -WITH GASOLINE EN-		<b>FOR RUSSIA .....</b>	<b>122</b>
GINE- .....	50	FOR RUSSIA : Precaution for Supplemental Re-	
LHD : Wiring Diagram -WITH DIESEL ENGINE-	51	straint System (SRS) "AIR BAG" and "SEAT BELT	
<b>RHD .....</b>	<b>51</b>	PRE-TENSIONER" .....	122
RHD : Wiring Diagram -WITH GASOLINE EN-		FOR RUSSIA : Precaution Necessary for Steering	
GINE- .....	52	Wheel Rotation after Battery Disconnect .....	122
RHD : Wiring Diagram -WITH DIESEL ENGINE-	53	FOR RUSSIA : Precaution for Procedure without	
<b>HEADLAMP WASHER SYSTEM .....</b>	<b>54</b>	Cowl Top Cover .....	123
<b>LHD .....</b>	<b>54</b>	<b>EXCEPT FOR RUSSIA .....</b>	<b>123</b>
LHD : Wiring Diagram .....	54	EXCEPT FOR RUSSIA : Precaution for Supple-	
<b>RHD .....</b>	<b>54</b>	mental Restraint System (SRS) "AIR BAG" and	
RHD : Wiring Diagram .....	55	"SEAT BELT PRE-TENSIONER" .....	123
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>56</b>	EXCEPT FOR RUSSIA : Precaution Necessary	
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>56</b>	for Steering Wheel Rotation after Battery Discon-	
Reference Value .....	56	nect .....	123
Wiring Diagram - BCM (Gasoline Engine Models)		EXCEPT FOR RUSSIA : Precaution for Battery	
- .....	81	Service (for V9X Models) .....	124
Wiring Diagram - BCM (Diesel Engine Models) -	86	EXCEPT FOR RUSSIA : Precaution for Proce-	
Fail-safe .....	90	dure without Cowl Top Cover .....	124
DTC Inspection Priority Chart .....	93	<b>REMOVAL AND INSTALLATION .....</b>	<b>125</b>
DTC Index .....	94	<b>HEADLAMP WASHER NOZZLE AND TUBE..</b>	<b>125</b>
<b>IPDM E/R (INTELLIGENT POWER DISTRI-</b>		Exploded View .....	125
<b>BUTION MODULE ENGINE ROOM) .....</b>	<b>97</b>	Hydraulic Layout .....	125
Reference Value .....	97	Removal and Installation .....	125
Wiring Diagram - IPDM E/R (Gasoline Engine) -	105	Inspection .....	126
Wiring Diagram - IPDM E/R (Diesel Engine) -	108	<b>WASHER TANK .....</b>	<b>128</b>
Fail-safe .....	110	Exploded View .....	128
DTC Index .....	112	Removal and Installation .....	128
<b>SYMPTOM DIAGNOSIS .....</b>	<b>113</b>	<b>WASHER PUMP .....</b>	<b>129</b>
<b>WIPER AND WASHER SYSTEM SYMPTOMS</b>		Exploded View .....	129
<b>. 113</b>		Removal and Installation .....	129
		<b>HEADLAMP WASHER PUMP .....</b>	<b>130</b>

Exploded View .....	130	<b>LIGHT &amp; RAIN SENSOR .....</b>	<b>141</b>	
Removal and Installation .....	130	Exploded View .....	141	A
<b>WASHER LEVEL SWITCH .....</b>	<b>131</b>	Removal and Installation .....	141	
Removal and Installation .....	131	<b>WIPER AND WASHER SWITCH .....</b>	<b>142</b>	B
<b>FRONT WASHER NOZZLE AND TUBE .....</b>	<b>132</b>	Exploded View .....	142	
Hydraulic Layout .....	132	<b>REAR WIPER ARM .....</b>	<b>143</b>	C
Removal and Installation .....	132	Exploded View .....	143	
Inspection and Adjustment .....	132	Removal and Installation .....	143	
<b>FRONT WIPER ARM .....</b>	<b>135</b>	Adjustment .....	143	D
Exploded View .....	135	<b>REAR WIPER MOTOR .....</b>	<b>145</b>	
Removal and Installation .....	135	Exploded View .....	145	
Adjustment .....	135	Removal and Installation .....	145	E
<b>WIPER BLADE .....</b>	<b>137</b>	<b>REAR WASHER NOZZLE AND TUBE .....</b>	<b>146</b>	
Exploded View .....	137	Hydraulic Layout .....	146	
Removal and Installation .....	137	Removal and Installation .....	146	F
Replacement .....	137	Inspection and Adjustment .....	147	
<b>FRONT WIPER DRIVE ASSEMBLY .....</b>	<b>139</b>	<b>HEADLAMP WASHER SWITCH .....</b>	<b>148</b>	G
Exploded View .....	139	Exploded View .....	148	
Removal and Installation .....	139	Removal and Installation .....	148	
Disassembly and Assembly .....	140			H

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000004965866

#### OVERALL SEQUENCE



JPLIA0313GB

#### DETAILED FLOW

##### 1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### FRONT WIPER AND WASHER SYSTEM

#### System Diagram



#### System Description

INFOID:000000004965868

#### OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

##### Control by BCM

- Combination switch reading function
- Front wiper control function

##### Control by IPDM E/R

- Front wiper control function
- Relay control function

#### FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

#### FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

##### Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

#### FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

##### Front wiper HI operating condition

- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

#### FRONT WIPER AUTO OPERATION

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

### Rain Sensing

Rain level and sensor conditions are detected by light & rain sensor.

- BCM transmits the vehicle conditions (vehicle speed, front wiper condition, light & rain sensor sensitivity setting, etc.) to the light & rain sensor via the light & rain sensor serial link.
- Light & rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. And it transmits the wiping speed request signal to the BCM via the light & rain sensor serial link.

### Auto Wiping Operation

- BCM receives the wiping speed request signal from the light & rain sensor via the light & rain sensor serial link.
- BCM controls front wiper operation according to the wiping speed request signals. And it transmits the front wiper request signals (LO or HI) to the IPDM E/R via CAN communication line.

Front wiper AUTO operating condition

- Ignition switch ON
- Front wiper switch AUTO

### NOTE:

When the front wiper switch is turned to AUTO position, front wiper operates once regardless of a rainy condition.

### Light & rain Sensor Sensitivity Setting

BCM determines light & rain sensor sensitivity according to a wiper volume.


Wiper volume dial position	Sensitivity
1	High sensitivity
2	
3	Medium – high sensitivity
4	
5	Low – medium sensitivity
6	
7	Low sensitivity

### NOTE:

When the wiper volume is turned up at 1 level with front wiper AUTO operating condition, front wiper operates once.

### FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper stop position signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).
- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



### NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch OFF.

# FRONT WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

---

### FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 2 times when the front washer switch OFF is detected.

Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The washer pump is grounded through the combination switch when the front washer switch ON.

### FRONT WIPER DROP WIPE OPERATION

- BCM controls the front wiper to operate once according to the conditions of front wiper drop wipe operation.

Front wiper drop wipe operating condition

- Ignition switch ON
- Front wiper switch OFF
- Front washer switch OFF
- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication so that the front wiper operate once three seconds after front wiper operation linked with washer.
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

### FAIL-SAFE FUNCTION

Front Wiper control

IPDM E/R performs the fail-safe function when the front wiper auto stop circuit is malfunctioning. Refer to [PCS-35. "Fail-safe"](#).

Light & rain Sensor Malfunction

- BCM judges the light & rain sensor serial link error by the light & rain sensor serial link condition and detects the light & rain sensor malfunction by light & rain sensor malfunction signal.
- When BCM detects the light & rain sensor serial link error or the light & rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

**NOTE:**


If light & rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is AUTO position, BCM operates front wiper LO.

# FRONT WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000004965869



- |                               |                                       |                             |
|-------------------------------|---------------------------------------|-----------------------------|
| 1. Combination switch         | 2. Light & rain sensor                | 3. BCM                      |
| 4. IPDM E/R                   | 5. Washer pump                        | 6. Front wiper motor        |
| 7. Unified meter and A/C amp. |                                       |                             |
| A. Wind shield upper          | B. Dash side lower (passenger side)   | C. Engine room (right side) |
| D. Radiator core support (RH) | E. Cowl top, left side of engine room | F. Behind cluster lid C     |

## Component Description

INFOID:0000000005370219

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges the each switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R.</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>Controls the integrated relay according to the request (with CAN communication) from BCM.</li> <li>Performs the auto stop control of the front wiper.</li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

## FRONT WIPER AND WASHER SYSTEM

### < SYSTEM DESCRIPTION >

Part	Description
Front wiper motor	<ul style="list-style-type: none"><li>• IPDM E/R controls front wiper operation.</li><li>• Front wiper auto stop signal is transmitted to IPDM E/R.</li></ul>
Washer pump	<ul style="list-style-type: none"><li>• Washer fluid is sprayed according to washer switch states.</li><li>• Switching between front washer and rear washer is performed according to the voltage polarity change to washer pump.</li></ul>
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-13. "System Description"</a> .
Unified meter and A/C amp.	Transmits the vehicle speed signal to BCM with CAN communication.
Light & rain sensor	Detects water droplets on the windshield with infrared rays, and transmits the light & rain sensor signal to BCM through the light and light & rain sensor serial link.


# REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## REAR WIPER AND WASHER SYSTEM

### System Diagram

INFOID:000000006055143



\*1 : AT models

\*2 : MT models

### System Description

INFOID:000000004965872

#### OUTLINE

The rear wiper is controlled by each function of BCM.

Control by BCM

- Combination switch reading function
- Rear wiper control function

#### REAR WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM controls the rear wiper to start or stop.

#### REAR WIPER ON OPERATION

- BCM supplies power to the rear wiper motor according to the rear wiper ON operating condition.

Rear wiper ON operating condition

- Ignition switch ON
- Rear wiper switch ON

#### REAR WIPER INT OPERATION

- BCM supplies power to the rear wiper motor according to the INT operating condition.

Rear wiper INT operating condition

- Ignition switch ON
- Rear wiper switch INT
- BCM controls the rear wiper to operate once.
- BCM detects the rear wiper motor stopping position.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# REAR WIPER AND WASHER SYSTEM


## < SYSTEM DESCRIPTION >

- BCM supplies power to the rear wiper motor after an intermittent from the stop of the rear wiper motor.



## REAR WIPER AUTO STOP OPERATION

- BCM stops supplying power to the rear wiper motor when the rear wiper switch is turned OFF.
- BCM reads a rear wiper stop position signal from the rear wiper motor to detect a rear wiper motor position.
- When the rear wiper motor is at other than the stopping position, BCM continues to supply power to the rear wiper motor until it returns to the stopping position.



### NOTE:

BCM stops supplying power to the rear wiper motor when the ignition switch is turned OFF.

## REAR WIPER OPERATION LINKED WITH WASHER

- BCM supplies power to the rear wiper motor according to the washer linked operating condition of rear wiper. When the rear washer switch is turned OFF, BCM controls rear wiper to operate approximately 3 times.

Washer linked operating condition of rear wiper

- Ignition switch ON
- Rear washer switch ON (0.4 second or more)
- The washer pump is grounded through the combination switch with the rear washer switch ON.

## REAR WIPER OPERATION LINKED WITH REVERSE

- BCM controls rear wiper to operate once according to the conditions of rear wiper operation linked with reverse.

Condition of rear wiper operation linked with reverse

- Ignition switch ON
- Front wiper switch: LO, HI or INT
- Rear wiper switch OFF
- Selector lever "R" (AT models)
- Shift lever "R" (MT models)
- TCM transmits the shift position signal to BCM through the CAN communication line when the selector lever is shifted to the "R". (AT models)
- Back-up lamp switch transmits the back-up lamp switch signal to BCM when the shift lever is shifted to the "R". (MT models)
- BCM supplies power to the rear wiper motor when receiving the shift position signal (AT models) or back-up lamp signal (MT models).

# REAR WIPER AND WASHER SYSTEM

## < SYSTEM DESCRIPTION >

### REAR WIPER DROP WIPE OPERATION

- BCM controls the rear wiper to operate once according to the rear wiper drop wipe operating condition.

Rear wiper drop wipe operating condition


- Ignition switch ON
- Rear wiper switch OFF
- Rear washer switch OFF
- BCM controls the rear wiper so that it operates once approximately three seconds after the washer interlocking operation of the rear wiper.

### REAR WIPER FAIL-SAFE OPERATION

BCM performs the fail-safe function when the rear wiper auto stop circuit is malfunctioning. Refer to [BCS-84](#), "[Fail-safe](#)".

### Component Parts Location

INFOID:000000004965873



- |                                     |  |                                    |
|-------------------------------------|--|------------------------------------|
| 1. Combination switch               | 2. • TCM (AT models)<br>Refer to <a href="#">TM-44</a> , " <a href="#">A/T CONTROL SYSTEM : Component Parts Location</a> ".<br>• Back-up lamp switch (MT models)<br>Refer to <a href="#">TM-12</a> , " <a href="#">Component Parts Location</a> ". | 3. BCM                             |
| 4. Washer pump                      | 5. Rear wiper motor  |                                    |
| A. Dash side lower (passenger side) | B. Radiator core support (RH)  | C. Back door finisher inner inside |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# REAR WIPER AND WASHER SYSTEM

< SYSTEM DESCRIPTION >

## Component Description

INFOID:000000005370221


Part	Description
BCM	<ul style="list-style-type: none"><li>• Judges each switch status by the combination switch reading function.</li><li>• Supplies power to the rear wiper motor.</li><li>• Performs the auto stop control of the rear wiper.</li></ul>
TCM (AT models)	Transmits the shift position signal to BCM with CAN communication.
Back-up lamp switch (MT models)	Transmits the back-up lamp switch signal to BCM.
Rear wiper motor	<ul style="list-style-type: none"><li>• BCM controls rear wiper operation.</li><li>• Rear wiper auto stop signal is transmitted to BCM.</li></ul>
Washer pump	<ul style="list-style-type: none"><li>• Washer fluid is sprayed according to washer switch states.</li><li>• Switching between front washer and rear washer is performed according to the voltage polarity change to washer pump.</li></ul>
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-13. "System Description"</a> .

# HEADLAMP WASHER SYSTEM

< SYSTEM DESCRIPTION >

## HEADLAMP WASHER SYSTEM FOR EUROPE

### FOR EUROPE : System Diagram



### FOR EUROPE : System Description

INFOID:000000004965876

#### OUTLINE

Headlamp washer is controlled by each function of BCM and IPDM E/R.

Control by BCM


- Combination switch reading function
- Headlamp washer control function

Control by IPDM E/R

- Headlamp washer relay control function

#### HEADLAMP WASHER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the headlamp washer request signal to IPDM E/R with CAN communication depending on each operating condition of the headlamp washer.



Operation is front washer switch (The first time)

- Ignition switch ON
- Headlamps ON
- Front washer switch ON at first time

Operation is front washer switch (From the second time)

- Ignition switch ON

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


# HEADLAMP WASHER SYSTEM

## < SYSTEM DESCRIPTION >

- Headlamps ON
- Front washer switch ON at fifth time after the first time
- IPDM E/R turns ON/OFF the headlamp washer relay by receiving the headlamp washer request signal, and controls the headlamp washer.

## FOR EUROPE : Component Parts Location

INFOID:000000004965877



- |                                     |                             |                               |
|-------------------------------------|-----------------------------|-------------------------------|
| 1. Combination switch               | 2. BCM                      | 3. IPDM E/R                   |
| 4. Headlamp washer pump             |                             |                               |
| A. Dash side lower (Passenger side) | B. Engine room (right side) | C. Radiator core support (RH) |

## FOR EUROPE : Component Description

INFOID:000000004965878

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Judges the each switch status by the combination switch reading function.</li> <li>• Requests (with CAN communication) the headlamp washer relay ON to IPDM E/R.</li> </ul>
IPDM E/R	Controls the integrated relay according to the request (with CAN communication) from BCM.
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-13, "System Description"</a> .


## FOR RUSSIA

# HEADLAMP WASHER SYSTEM

< SYSTEM DESCRIPTION >

## FOR RUSSIA : System Diagram

INFOID:000000006054683



## FOR RUSSIA : System Description

INFOID:000000006054684

### OUTLINE

- Headlamp washer system has following two operations.
  - Normal operation by the headlamp washer switch
  - Operation linked with front washer
- Headlamp washer is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Headlamp washer control function

#### Control by IPDM E/R

- Headlamp washer relay control function

### HEADLAMP WASHER OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the headlamp washer request signal to IPDM E/R with CAN communication depending on each operating condition of the headlamp washer.

#### Operation is headlamp washer switch

- Ignition switch ON
- Headlamps ON
- Headlamp washer switch ON

#### Operation is front washer switch (The first time)

- Ignition switch ON
- Headlamps ON
- Front washer switch ON at first time

#### Operation is front washer switch (From the second time)

- Ignition switch ON
- Headlamps ON
- Front washer switch ON at fifth time after the first time
- IPDM E/R turns ON/OFF the headlamp washer relay by receiving the headlamp washer request signal, and controls the headlamp washer.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P


WW

# HEADLAMP WASHER SYSTEM

< SYSTEM DESCRIPTION >

## FOR RUSSIA : Component Parts Location

INFOID:000000006054698



- |                                     |                             |                               |
|-------------------------------------|-----------------------------|-------------------------------|
| 1. Combination switch               | 2. Headlamp washer switch   | 3. BCM                        |
| 4. IPDM E/R                         | 5. Headlamp washer pump     |                               |
| A. Dash side lower (Passenger side) | B. Engine room (right side) | C. Radiator core support (RH) |

## FOR RUSSIA : Component Description

INFOID:000000006055130

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges the each switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the headlamp washer relay ON to IPDM E/R.</li> </ul>
IPDM E/R	Controls the integrated relay according to the request (with CAN communication) from BCM.
Combination switch (Wiper & washer switch)	Refer to <a href="#">BCS-13. "System Description"</a> .
Headlamp washer switch	Headlamp washer switch inputs the signals to BCM when pressing the switch.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005406782

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>• Read and save the vehicle specification.</li> <li>• Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER		×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*			
<ul style="list-style-type: none"> <li>• Intelligent Key system</li> <li>• Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×

#### NOTE:

\*: This item is displayed, but is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK".)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)		
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>	

## WIPER

### WIPER : CONSULT-III Function (BCM - WIPER)

INFOID:000000006055150

## DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [Off/On]	The switch status input from push-button ignition switch.
VEHICLE SPEED 1 [km/h]	The value of the vehicle speed signal received from unified meter and A/C amp. with CAN communication.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
FR WIPER HI [Off/On]	Each switch status that BCM judges from the combination switch reading function.
FR WIPER LOW [Off/On]	
FR WASHER SW [Off/On]	
FR WIPER INT [Off/On]	
FR WIPER STOP [Off/On]	Front wiper motor (stop position) status received from IPDM E/R with CAN communication.
INT VOLUME [1 – 7]	Each switch status that BCM judges from the combination switch reading function.
RR WIPER ON [Off/On]	Each switch status that BCM judges from the combination switch reading function.
RR WIPER INT [Off/On]	
RR WASHER SW [Off/On]	
RR WIPER STOP [Off/On]	Rear wiper motor (stop position) status input from the rear wiper motor.
REVERSE SW CAN [Off/On]	Reverse switch status received from TCM with CAN communication.
H/L WASH SW* [Off/On]	The switch status input from headlamp washer switch.

\*: For models with headlamp washer switch

## ACTIVE TEST

Test item	Operation	Description
FR WIPER	Hi	Transmits the front wiper request signal (HI) to IPDM E/R with CAN communication to operate the front wiper HI operation.
	Lo	Transmits the front wiper request signal (LO) to IPDM E/R with CAN communication to operate the front wiper LO operation.
	INT	Transmits the front wiper request signal (INT) to IPDM E/R with CAN communication to operate the front wiper INT operation.
	Off	Stops transmitting the front wiper request signal to stop the front wiper operation.
RR WIPER	On	Outputs the voltage to operate the rear wiper motor.
	Off	Stops the voltage to stop.
HEADLAMP WASHER	On	Transmits the headlamp washer request signal to IPDM E/R with CAN communication to operate the headlamp washer operation.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000005406793

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

##### Operation Procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)  
**NOTE:**  
When auto active test is performed with hood opened, sprinkle water on windshield beforehand.
2. Turn the ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.  
**CAUTION:**  
**Close passenger door.**
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

##### NOTE:

When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.

##### CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-75](#), "[Component Function Check](#)".
- Do not start the engine.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 5 steps are repeated 3 times.


Operation sequence	Inspection location	Operation
A	Oil pressure warning lamp	Blinks continuously during operation of auto active test
1	Front wiper	LO for 5 seconds → HI for 5 seconds
2	<ul style="list-style-type: none"><li>• Parking lamps</li><li>• License plate lamps</li><li>• Tail lamps</li><li>• Front fog lamps</li></ul>	10 seconds
3	Headlamps	<ul style="list-style-type: none"><li>• LO 10 seconds</li><li>• HI ON ↔ OFF 5 times</li></ul>
4	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
5*	Cooling fan	MID for 5 seconds → HI for 5 seconds

\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• Unified meter and A/C amp. signal input circuit</li> <li>• CAN communication signal between unified meter and A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and unified meter and A/C amp.</li> <li>• Combination meter</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Symptom	Inspection contents	Possible cause
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Cooling fan</li> <li>• Harness or connector between cooling fan and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connector between IPDM E/R and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000005406794

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [WW-112. "DTC Index"](#).

### DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIG- NALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NALS	Description
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the clutch interlock switch (M/T models) or shift position (A/T models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST /INHI/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay request received from BCM via CAN communication.
S/L STATE [LOCK/UNLOCK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only the vehicle with daytime running light system.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		Displays the status of the headlamp washer request signal received from BCM via CAN communication.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.
CRNRNG LMP REQ [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.

## ACTIVE TEST

Test item

Test item	Operation	Description
CORNERING LAMP	Off	<b>NOTE:</b> The item is indicated, but cannot be tested.
	LH	
	RH	
HORN	On	Operates horn relay for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.

## DIAGNOSIS SYSTEM (IPDM E/R)

### < SYSTEM DESCRIPTION >

Test item	Operation	Description
MOTOR FAN	1	OFF
	2	Outputs 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Outputs 80% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Outputs 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	Operates the headlamp washer relay for 1 second.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and the daytime running light relay. <b>NOTE:</b> Daytime running light relay is with daytime running light system only.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

# WIPER AND WASHER FUSE

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### WIPER AND WASHER FUSE

#### Diagnosis Procedure

INFOID:000000004965884

#### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

Unit	Location	No.	Capacity
Front wiper motor	IPDM E/R	60	30 A
Washer pump	IPDM E/R	47	10 A
Headlamp Washer pump	Fuse and fusible link block	I	40 A

#### Is the fuse or fusible link fusing?

- YES >> Replace the fuse block or fusible link with a new one after repairing the applicable circuit.  
NO >> The fuse is normal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# FRONT WIPER MOTOR LO CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR LO CIRCUIT

### Component Function Check

INFOID:0000000053702.14

#### 1. CHECK FRONT WIPER LO OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [WW-22, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO operation.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

**Lo** : Front wiper (LO) operation

**Off** : Stop the front wiper.

Is front wiper (LO) operation normally?

- YES >> Front wiper motor LO circuit is normal.  
NO >> Refer to [WW-28, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000053702.15

#### 1. CHECK FRONT WIPER MOTOR (LO) OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Select "FRONT WIPER" of IPDM E/R active test item.
5. With operating the test item, check voltage between front wiper motor harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Front wiper motor		FRONT WIPER	Battery voltage
Connector	Terminal		
E42	1	Lo	Battery voltage
		Off	0 V

Is the measurement value normal?

- YES >> Replace front wiper motor.  
NO >> GO TO 2.

#### 2. CHECK FRONT WIPER MOTOR (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E5	4	E42	1	Existed

Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK FRONT WIPER MOTOR (LO) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

# FRONT WIPER MOTOR LO CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	4		Not existed

### Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace IPDM E/R.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER MOTOR HI CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR HI CIRCUIT

### Component Function Check

INFOID:0000000053702.16

#### 1. CHECK FRONT WIPER HI OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [WW-22, "Diagnosis Description"](#).
2. Check that the front wiper operates at the HI operation.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check front wiper operation.

**Hi** : Front wiper (HI) operation

**Off** : Stop the front wiper.

Is front wiper (HI) operation normally?

YES >> Front wiper motor HI circuit is normal.

NO >> Refer to [WW-30, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000053702.17

#### 1. CHECK FRONT WIPER MOTOR (HI) OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Select "FRONT WIPER" of IPDM E/R active test item.
5. With operating the test item, check voltage between front wiper motor harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Front wiper motor		FRONT WIPER	Battery voltage
Connector	Terminal		
E42	4	Hi	Battery voltage
		Off	0 V

Is the measurement value normal?

YES >> Replace front wiper motor.

NO >> GO TO 2.

#### 2. CHECK FRONT WIPER MOTOR (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E5	5	E42	4	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK FRONT WIPER MOTOR (HI) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

# FRONT WIPER MOTOR HI CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	5		Not existed

### Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace IPDM E/R.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:000000005370223

#### 1.CHECK FRONT WIPER (AUTO STOP) SIGNAL

##### CONSULT-III DATA MONITOR

1. Select "WIP AUTO STOP" of IPDM E/R data monitor item.
2. Operate the front wiper.
3. With the front wiper operation, check the monitor status.

Monitor item	Condition		Monitor status
WIP AUTO STOP	Front wiper motor	Stop position	STOP P
		Except stop position	ACT P

Is the status of item normal?

- YES >> Auto stop signal circuit is normal.  
NO >> Refer to [WW-32, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005370224

#### 1.CHECK FRONT WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between front wiper motor harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Front wiper motor		Battery voltage
Connector	Terminal	
E42	5	

Is the measurement value normal?

- YES >> Replace front wiper motor.  
NO >> GO TO 2.

#### 2.CHECK FRONT WIPER MOTOR (AUTO STOP) CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E5	16	E42	5	Existed

Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK FRONT WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	16		Not existed

# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

---

Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace IPDM E/R.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER MOTOR GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FRONT WIPER MOTOR GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000005370225

#### 1. CHECK FRONT WIPER MOTOR (GND) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor connector.
3. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		Existed
E42	2		

#### Does continuity exist?

- YES >> Front wiper motor ground circuit is normal.  
NO >> Repair or replace harness.

# WASHER SWITCH


< DTC/CIRCUIT DIAGNOSIS >

## WASHER SWITCH

### Description

INFOID:000000004965894

- Washer switch is integrated with combination switch.
- Combination switch switches polarity between front washer operating and rear washer operating to supply power to the washer pump on ground.




### Component Inspection

INFOID:000000004965895

#### 1. CHECK WIPER SWITCH

1. Turn the ignition switch OFF.
2. Disconnect combination switch connector.
3. Check continuity between the combination switch terminals.

- A : Terminal 4  
 B : Terminal 6  
 C : Terminal 3  
  
 D : Terminal 1



JPLIA0164GB

Combination switch		Condition	Continuity
Terminal			
1	6	Front washer switch ON	Existed
3	4		
1	4	Rear washer switch ON	
3	6		

#### Does continuity exist?

- YES >> Wiper and washer switch is normal.  
 NO >> Replace combination switch (Wiper and washer switch).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# LIGHT & RAIN SENSOR


< DTC/CIRCUIT DIAGNOSIS >

## LIGHT & RAIN SENSOR

### Description

INFOID:000000005370226

Light & rain sensor judges a wiping speed for front wiper by rain condition and the vehicle conditions. And it transmits the wiping speed request signal to the BCM via the light & rain sensor serial link.



### Component Function Check

INFOID:000000005370227

#### 1. CHECK FRONT WIPER AUTO OPERATION

1. Clean light & rain sensor detection area of windshield fully.
2. When the front wiper switch is turned to AUTO position, front wiper operates once regardless of a rainy condition.

Is front wiper (AUTO) operation normally?

- YES >> Light & rain sensor circuit is normal.  
NO >> Refer to [WW-36, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005370228

#### 1. CHECK LIGHT & RAIN SENSOR FUSE

1. Turn the ignition switch OFF.
2. Check that the light & rain sensor 10A fuse (#6) is not fusing.

Is the fuse fusing?

- YES >> Replace the fuse after repairing the applicable circuit.  
NO >> GO TO 2.

#### 2. CHECK LIGHT & RAIN SENSOR POWER SUPPLY

1. Disconnect light & rain sensor connector.
2. Check voltage between light & rain sensor harness connector and ground.

Terminal		Terminal	Voltage (Approx.)
(+)	(-)		
Light & rain sensor connector			
R9	1	Ground	Battery voltage

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK LIGHT & RAIN SENSOR GROUND CIRCUIT

Check continuity between light & rain sensor harness connector and ground.

Light & rain sensor		Ground	Continuity
Connector	Terminal		
R9	3		Existed

Does continuity exist?


# LIGHT & RAIN SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 4. CHECK LIGHT & RAIN SENSOR SIGNAL

1. Connect light & rain sensor connector.
2. Turn the ignition switch ON.
3. Check signal between BCM harness connector and the ground with oscilloscope.

Terminal (+)		Terminal (-)	Condition	Signal (Reference value)
BCM connector	Terminal			
M123	112	Ground	Ignition switch ON	 <p style="text-align: center;">Approx. 8.7V</p>

Is the measurement value normal?

- YES >> Replace light & rain sensor. Refer to [WW-141, "Exploded View"](#).  
 NO >> GO TO 5.

### 5. CHECK LIGHT & RAIN SENSOR SIGNAL CIRCUIT FOR OPEN

1. Disconnect BCM connector and light & rain sensor connector.
2. Check continuity between BCM harness connector and light & rain sensor harness connector.

BCM		Light & rain sensor		Continuity
Connector	Terminal	Connector	Terminal	
M123	112	R9	2	Existed

Does continuity exist?

- YES >> GO TO 6.  
 NO >> Repair or replace harness.

### 6. CHECK LIGHT & RAIN SENSOR SIGNAL CIRCUIT FOR SHORT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	112		Not existed

Does continuity exist?

- YES >> Repair or replace harness.  
 NO >> Replace BCM. Refer to [BCS-94, "Exploded View"](#).

# REAR WIPER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER MOTOR CIRCUIT

### Component Function Check

INFOID:000000005370231

#### 1. CHECK REAR WIPER ON OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "RR WIPER" of BCM active test item.
2. With operating the test item, check rear wiper operation.

**On** : Rear wiper ON operation

**Off** : Stop the rear wiper.

##### Is rear wiper operation normally?

- YES >> Rear wiper motor circuit is normal.  
NO >> Refer to [WW-38, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005370232

#### 1. CHECK REAR WIPER MOTOR OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor connector.
3. Turn the ignition switch ON.
4. Select "RR WIPER" of BCM active test item.
5. With operating the test item, check voltage between rear wiper motor harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Rear wiper motor		REAR WIPER	Battery voltage
Connector	Terminal		
D115	2	On	
		Off	

##### Is the measurement value normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

#### 2. CHECK REAR WIPER MOTOR OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear wiper motor harness connector.

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M120	26	D115	2	Existed

##### Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK REAR WIPER MOTOR SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

# REAR WIPER MOTOR CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M120	26		Not existed

### Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace BCM. Refer to [BCS-94. "Exploded View"](#).

## 4.CHECK REAR WIPER MOTOR GROUND OPEN CIRCUIT

Check continuity between rear wiper motor harness connector and ground.

Rear wiper motor		Ground	Continuity
Connector	Terminal		
D115	4		Existed

### Does continuity exist?

YES >> Replace rear wiper motor.

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# REAR WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:000000005370233

#### 1.CHECK REAR WIPER (AUTO STOP) OPERATION

##### CONSULT-III DATA MONITOR

1. Select "WIPER" of BCM data monitor item.
2. Operate the rear wiper.
3. Check that "RR WIPER STOP" changes to "On" and "Off" linked with the wiper operation.

Monitor item	Condition		Monitor status
RR WIPER STOP	Rear wiper motor	Stop position	On
		Except stop position	Off

##### Is the status of item normal?

- YES >> Rear wiper auto stop signal circuit is normal.  
NO >> Refer to [WW-40, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005370234

#### 1.CHECK REAR WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor connector.
3. Turn the ignition switch ON.
4. Check voltage between rear wiper motor harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Rear wiper motor		Battery voltage
Connector	Terminal	
D115	3	

##### Is the measurement value normal?

- YES >> Replace rear wiper motor.  
NO >> GO TO 2.

#### 2.CHECK REAR WIPER MOTOR (AUTO STOP) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear wiper motor harness connector.

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M121	65	D115	3	Existed

##### Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK REAR WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M121	65		Not existed

# REAR WIPER AUTO STOP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

---

Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace BCM. Refer to [BCS-94, "Exploded View"](#).

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# HEADLAMP WASHER RELAY

< DTC/CIRCUIT DIAGNOSIS >

## HEADLAMP WASHER RELAY

### Component Inspection

INFOID:000000004965903

#### 1. CHECK HEADLAMP WASHER RELAY

1. Turn the ignition switch OFF.
2. Disconnect headlamp washer relay.
3. Apply battery voltage to headlamp washer relay between terminals 1 and 2.
4. Check continuity of headlamp washer relay.

Headlamp washer relay		Condition	Continuity
Terminal		Voltage	
3	5	Apply	Existed
		Not Apply	Not existed

#### Does continuity exist?

- YES >> Headlamp washer relay is normal.  
NO >> Replace headlamp washer relay.

# HEADLAMP WASHER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## HEADLAMP WASHER SWITCH

### Description

INFOID:000000006054687

Headlamp washer switch inputs the signals to BCM when pressing the switch.

### Component Function Check

INFOID:000000006054688

#### 1. CHECK HEADLAMP SWITCH SIGNAL BY CONSULT-III

##### CONSULT-III DATA MONITOR

1. Turn the ignition switch ON.
2. Select "H/L WASH SW" of BCM data monitor item.
3. With operating the headlamp washer switch, check the monitor status.

Monitor item	Condition		Monitor status
H/L WASH SW	Headlamp washer switch	While pressing	On
		While not pressing	Off

Is the item status normal?


- YES >> Headlamp washer switch circuit is normal.  
 NO >> Refer to [WW-43, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006054689

#### 1. CHECK HEADLAMP WASHER SWITCH SIGNAL INPUT

With operating the headlamp washer switch, check the voltage between the BCM harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM		Headlamp Washer switch	0 V
Connector	Terminal		
M123	127	Ground	
		While not pressing	

JPMIA0154GB

Is the measurement value normal?

- YES >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK HEADLAMP WASHER SWITCH SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the headlamp washer switch connector and BCM connector.
3. Check continuity between the headlamp washer switch harness connector and the BCM harness connector.

Headlamp washer switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M214	1	M123	127	Existed

Does continuity exist?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## HEADLAMP WASHER SWITCH

### < DTC/CIRCUIT DIAGNOSIS >

---

- YES >> GO TO 3.  
NO >> Repair the harness or connector.

### 3.CHECK HEADLAMP WASHER SWITCH SIGNAL SHORT CIRCUIT

---

Check continuity between the headlamp washer switch harness connector and the ground.

Headlamp washer switch		Ground	Continuity
Connector	Terminal		
M214	1		Not existed

#### Does continuity exist?

- YES >> Repair the harness or connector.  
NO >> GO TO 4.

### 4.CHECK HEADLAMP WASHER SWITCH GROUND OPEN CIRCUIT

---

Check continuity between the headlamp washer switch harness connector and the ground.

Headlamp washer switch		Ground	Continuity
Connector	Terminal		
M214	2		Existed

#### Does continuity exist?

- YES >> Replace headlamp washer switch.  
NO >> Repair the harness or connector.

# HEADLAMP WASHER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## HEADLAMP WASHER CIRCUIT

### Component Function Check

INFOID:000000005370235

#### 1.CHECK HEADLAMP WASHER OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "HEADLAMP WASHER" of IPDM E/R active test item.
2. With operating the test item, check headlamp washer operation.

**On** : Headlamp washer ON operation

**Off** : Stop the headlamp washer.

Is the headlamp washer operation normally?

- YES >> Headlamp washer circuit is normal.  
NO >> Refer to [WW-45, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005370236

#### 1.CHECK HEADLAMP WASHER FUSIBLE LINK

1. Turn the ignition switch OFF.
2. Check that the headlamp washer 40A fusible link (# I) is not fusing.

Is the fusible link fusing?

- YES >> Replace the fusible link after repairing the applicable circuit.  
NO >> GO TO 2.

#### 2.CHECK HEADLAMP WASHER RELAY POWER SUPPLY

1. Remove headlamp washer relay.
2. Check voltage between headlamp washer harness relay connector and ground.

Terminals		Voltage (Approx.)	
(+)	(-)		
Headlamp washer relay		Ground	Battery voltage
Connector	Terminal		
E51	1	Ground	Battery voltage
	3		

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3.CHECK HEADLAMP WASHER RELAY

Check headlamp washer relay. Refer to [WW-42, "Component Inspection"](#).

Is the headlamp washer relay normal?

- YES >> GO TO 4.  
NO >> Replace headlamp washer relay.

#### 4.CHECK HEADLAMP WASHER RELAY CONTROL SIGNAL OUTPUT

##### CONSULT-III ACTIVE TEST

1. Install headlamp washer relay.
2. Turn the ignition switch ON.
3. Select "HEADLAMP WASHER" of IPDM E/R active test item.
4. With operating the test item, check voltage between IPDM E/R harness connector and ground.

# HEADLAMP WASHER CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		HEADLAMP WASHER	0 V
Connector	Terminal		
E5	17	ON	0 V
		OFF	Battery voltage

Is the measurement value normal?

YES >> GO TO 7.

Fixed at 0 V >> GO TO 5.

Fixed at Battery voltage >> Replace IPDM E/R.

### 5. CHECK HEADLAMP WASHER RELAY CONTROL SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Remove headlamp washer relay.
3. Disconnect IPDM E/R harness connector.
4. Check continuity between IPDM E/R harness connector and headlamp washer relay harness connector.

IPDM E/R		Headlamp washer relay		Continuity
Connector	Terminal	Connector	Terminal	
E5	17	E51	2	Existed

Does continuity exist?

YES >> GO TO 6.

NO >> Repair or replace harness.

### 6. CHECK HEADLAMP WASHER RELAY CONTROL SIGNAL SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	17		Not existed

Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace IPDM E/R.

### 7. CHECK HEADLAMP WASHER PUMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect headlamp washer pump connector.
3. Remove headlamp washer relay.
4. Check continuity between headlamp washer relay harness connector and headlamp washer pump harness connector.

Headlamp washer relay		Headlamp washer pump		Continuity
Connector	Terminal	Connector	Terminal	
E51	5	E33	1	Existed

Does continuity exist?

YES >> GO TO 8.

NO >> Repair or replace harness.

### 8. CHECK HEADLAMP WASHER PUMP (GROUND) OPEN CIRCUIT

Check continuity between headlamp washer pump harness connector and ground.

# HEADLAMP WASHER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Headlamp washer pump		Ground	Continuity
Connector	Terminal		
E33	2		Existed

Does continuity exist?

YES >> Replace headlamp washer pump.

NO >> Repair or replace or harness.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


## FRONT WIPER AND WASHER SYSTEM

LHD

LHD : Wiring Diagram

INFOID:000000006069125

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12. "Connector Information"](#).



RHD

# FRONT WIPER AND WASHER SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

## RHD : Wiring Diagram

INFOID:000000006069126

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

### FRONT WIPER AND WASHER SYSTEM (RHD MODELS)



2010/01/25

JCLWM5258GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## REAR WIPER AND WASHER SYSTEM


LHD

LHD : Wiring Diagram -WITH GASOLINE ENGINE-

INFOID:000000006069165

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12. "Connector Information"](#).

### REAR WIPER AND WASHER SYSTEM (LHD MODELS WITH GASOLINE ENGINE)



2010/01/25

JCLWM5259GB

# REAR WIPER AND WASHER SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

## LHD : Wiring Diagram -WITH DIESEL ENGINE-

INFOID:000000006069166

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

### REAR WIPER AND WASHER SYSTEM (LHD MODELS WITH DIESEL ENGINE)



2010/01/25

JCLWM5261GB

RHD

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW


# REAR WIPER AND WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## RHD : Wiring Diagram -WITH GASOLINE ENGINE-

INFOID:000000006069132

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



2010/01/25

JCLWM5260GB

# REAR WIPER AND WASHER SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

## RHD : Wiring Diagram -WITH DIESEL ENGINE-

INFOID:000000006069133

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).

### REAR WIPER AND WASHER SYSTEM (RHD MODELS WITH DIESEL ENGINE)



2010/01/25

JCLWM5262GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# HEADLAMP WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## HEADLAMP WASHER SYSTEM


LHD

LHD : Wiring Diagram

INFOID:000000006069130

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12. "Connector Information"](#).

### HEADLAMP WASHER (LHD MODELS)



RHD

2010/01/25

JCLWM5263GB


# HEADLAMP WASHER SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

## RHD : Wiring Diagram

INFOID:000000006069131

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation: if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



2010/01/25

JCLWM5264GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

# ECU DIAGNOSIS INFORMATION

## BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000005406788

VALUES ON THE DIAGNOSIS TOOL

CONSULT-III MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch AUTO	Off
	Front wiper switch AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper volume dial is in a dial position 1 - 7	Wiper volume dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
RR FOG SW	Rear fog lamp switch OFF	Off	A
	Rear fog lamp switch ON	On	
DOOR SW-DR	Driver door closed	Off	B
	Driver door opened	On	
DOOR SW-AS	Passenger door closed	Off	C
	Passenger door opened	On	
DOOR SW-RR	Rear RH door closed	Off	D
	Rear RH door opened	On	
DOOR SW-RL	Rear LH door closed	Off	E
	Rear LH door opened	On	
DOOR SW-BK	Back door closed	Off	F
	Back door opened	On	
CDL LOCK SW	Other than power door lock switch LOCK	Off	G
	Power door lock switch LOCK	On	
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off	H
	Power door lock switch UNLOCK	On	
KEY CYL LK-SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	I
KEY CYL UN-SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	J
KEY CYL SW-TR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	K
HAZARD SW	Hazard switch is OFF	Off	
	Hazard switch is ON	On	
REAR DEF SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
H/L WASH SW <b>NOTE:</b> For models without headlamp washer switch, this item is not monitored.	Headlamp washer switch is not pressed	Off	
	Headlamp washer switch is pressed	On	
TR CANCEL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	WW
TR/BD OPEN SW	Back door opener switch OFF	Off	M
	While the back door opener switch is turned ON	On	
TRNK/HAT MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	N
SEN CANCEL SW	Sensor cancel switch is not pressed	Off	O
	Sensor cancel switch is pressed	On	
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off	P
	LOCK button of the Intelligent Key is pressed	On	
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off	
	UNLOCK button of the Intelligent Key is pressed	On	
RKE-TR/BD	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
RKE-PANIC	<b>NOTE:</b> The item is indicated, but not monitored.	Off	

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR <b>NOTE:</b> For models without optical sensor, this item is not monitored.	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -RL	<b>NOTE:</b> The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door opener request switch is not pressed	Off
	Back door opener request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
ACC RLY -F/B	<b>NOTE:</b> The item is indicated, but not monitored.	Off
CLUCH SW	The clutch pedal is not depressed	Off
	The clutch pedal is depressed	On
BRAKE SW 1	Brake pedal is depressed when No. 7 fuse is blown	Off
	Brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	Brake pedal is not depressed	Off
	Brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	<ul style="list-style-type: none"> <li>• Selector lever in any position other than P and N (A/T models)</li> <li>• Control lever in any position other than neutral (M/T models)</li> </ul>	Off
	<ul style="list-style-type: none"> <li>• Selector lever in P or N position (A/T models)</li> <li>• Control lever in neutral position (M/T models)</li> </ul>	On
S/L -LOCK	Steering is unlocked	Off
	Steering is locked	On
S/L -UNLOCK	Steering is locked	Off
	Steering is unlocked	On
S/L RELAY-F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off	A
	Ignition switch in ON position	On	
DETE SW -IPDM	Selector lever in any position other than P	Off	B
	Selector lever in P position	On	
SFT PN -IPDM	Selector lever in any position other than P and N	Off	C
	Selector lever in P or N position	On	
SFT P -MET	Selector lever in any position other than P	Off	D
	Selector lever in P position	On	
SFT N -MET	Selector lever in any position other than N	Off	E
	Selector lever in N position	On	
ENGINE STATE	Engine stopped	Stop	F
	While the engine stalls	Stall	
	At engine cranking	Crank	
	Engine running	Run	
S/L LOCK-IPDM	Steering is unlocked	Off	G
	Steering is locked	On	
S/L UNLK-IPDM	Steering is locked	Off	H
	Steering is unlocked	On	
S/L RELAY-REQ	Steering lock system is not the LOCK condition and the changing condition from LOCK to UNLOCK	Off	I
	Steering lock system is the LOCK condition or the changing condition from LOCK to UNLOCK	On	
VEH SPEED 1	While driving	Equivalent to speedometer reading	J
VEH SPEED 2	While driving	Equivalent to speedometer reading	
DOOR STAT-DR	Driver door is locked	LOCK	K
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Driver door is unlocked	UNLOCK	
DOOR STAT-AS	Passenger door is locked	LOCK	WW
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Passenger door is unlocked	UNLOCK	
ID OK FLAG	Steering is locked	Reset	M
	Steering is unlocked	Set	
PRMT ENG STRT	The engine start is prohibited	Reset	N
	The engine start is permitted	Set	
PRMT RKE STRT	<b>NOTE:</b> The item is indicated, but not monitored.	Reset	O
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off	P
	The Intelligent Key is inserted into key slot	On	
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key	
RKE OPE COUN2	<b>NOTE:</b> The item is indicated, but not monitored.	—	
REVERSE SW <b>NOTE:</b> For A/T models, this item is not monitored.	Control lever in any position other than reverse position	Off	
	Control lever in reverse position	On	

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT




PHYSICAL VALUES

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
3 (O)*2 (Y)*3	Ground	P/W power supply (RAP)	Output	Ignition switch ON		12 V
4 (P)	Ground	Interior room lamp power supply (Battery saver signal)	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		12 V
5*1 (G)	Ground	Super lock	Output	Super lock actuator	Actuator is activated	12 V
					Actuator is not activated	0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	12 V
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)	12 V
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Passenger door, rear RH door and rear LH door UNLOCK	Output	Passenger door, rear RH door and rear LH door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ACC or ON	0 V
17 (W)	Ground	Turn signal RH (Front and side)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 <p style="text-align: right; margin-right: 50px;">6.5 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >







Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
18 (O)	Ground	Turn signal LH (Front and side)	Output	Ignition switch OFF	0 V
				Ignition switch ON	Turn signal switch LH
19 (R) <sup>*4</sup> (SB) <sup>*5</sup>	Ground	Room lamp timer	Output	Other than under condition	5.0 V
				<ul style="list-style-type: none"> <li>• Interior room lamp timer is activated. (Door is unlocked. etc...)</li> <li>• Welcome light function is activated.</li> </ul>	0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch OFF	0 V
				Ignition switch ON	Turn signal switch RH
24 (R)	Ground	Rear fog lamp	Output	Rear fog lamp OFF	0 V
				Rear fog lamp ON	12 V
25 (G) <sup>*6</sup> (BR) <sup>*7</sup>	Ground	Turn signal LH (Rear)	Output	Ignition switch OFF	0 V
				Ignition switch ON	Turn signal switch LH
26 (P) <sup>*2</sup> (G) <sup>*3</sup>	Ground	Rear wiper	Output	Rear wiper OFF (Stopped)	0 V
				Rear wiper ON (Operated)	12 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
34 (SB)	Ground	Luggage room antenna (-)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0062GB</p>
				Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0063GB</p>
35 (V)	Ground	Luggage room antenna (+)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0062GB</p>
				Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0063GB</p>
38 (B)	Ground	Back door antenna (-)	Output	When the back door opener request switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0062GB</p>
				When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMkia0063GB</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	
				When Intelligent Key is not in the antenna detection area		
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V
48 (W)	Ground	Back door opener switch operation	Output	Back door opener switch	Not pressed	12 V
					Pressed	0 V
52 (LG)	Ground	Starter relay control	Output	Ignition switch ON (A/T models)	When selector lever is in P or N position	12 V
					When selector lever is not in P or N position	0 V
				Ignition switch ON (M/T models)	Battery voltage	
61 (W)	Ground	Back door opener request switch	Input	Back door opener request switch	ON (Pressed)	0 V
					OFF (Not pressed)	
64 (V)*4 (L)*5	Ground	Intelligent Key warning buzzer	Output	Intelligent Key warning buzzer	Sounding	0 V
					Not sounding	12 V
65 (O)	Ground	Rear wiper stop position	Input	Rear wiper	In stop position	
					Not in stop position	0 V
					1.0 V	
66 (LG)	Ground	Back door switch	Input	Back door switch	OFF (Door close)	12 V
					ON (Door open)	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
67 (P)	Ground	Back door opener switch	Input	Back door opener switch	Pressed	0 V
				Not pressed		
68 (BR)*6 (W)*7	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)	
				ON (Door open)	0 V	
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (Door close)	
				ON (Door open)	0 V	
72 (R)	Ground	Room antenna 2 (-) (Center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	
				When Intelligent Key is not in the passenger compartment		

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
73 (G)	Ground	Room antenna 2 (+) (Center console)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0062GB</p>
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMkia0063GB</p>
74 (SB)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0062GB</p>
				When Intelligent Key is not in the antenna detec- tion area	 <p style="text-align: right; font-size: small;">JMkia0063GB</p>
75 (BR)	Ground	Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ignition switch OFF	 <p style="text-align: right; font-size: small;">JMkia0062GB</p>
				When Intelligent Key is not in the antenna detec- tion area	 <p style="text-align: right; font-size: small;">JMkia0063GB</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the driver door request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the driver door request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
78 (Y)	Ground	Room antenna 1 (-) (Instrument panel)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is in the passenger compartment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
79 (BR)	Ground	Room antenna 1 (+) (Instrument panel)	Output	Ignition switch OFF	 <p style="text-align: right; font-size: small;">JMKIA0062GB</p>	
				When Intelligent Key is not in the passenger compartment	 <p style="text-align: right; font-size: small;">JMKIA0063GB</p>	
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (P) <sup>*2</sup> (R) <sup>*3</sup>	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
				ON	12 V	
83 (GR) <sup>*2</sup> (Y) <sup>*3</sup>	Ground	Remote keyless en- try receiver commu- nication	Input/ Output	During waiting	 <p style="text-align: right; font-size: small;">JMKIA0064GB</p>	
				When operating either button on the Intelli- gent Key	 <p style="text-align: right; font-size: small;">JMKIA0065GB</p>	
85 (G)	Ground	Alarm link	Input/ Output	Vehicle security system	Disarmed phase	12 V
				Pre-armed phase or armed phase	 <p style="text-align: right; font-size: small;">NNKIA0175ZZ</p>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
86*1 (O)	Ground	Dongle link	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelligent Key into the key slot.  Just after pressing ignition switch. Pointer of tester should move.	
87 (BR)*6 (W)*7	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JP MIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Front fog lamp switch ON (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JP MIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Rear fog lamp switch ON (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JP MIA0142GB</p> <p style="text-align: center;">1.2 V</p>
					Rear wiper switch ON (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JP MIA0039GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF	<ul style="list-style-type: none"> <li>• Wiper volume dial 1</li> <li>• Wiper volume dial 2</li> <li>• Wiper volume dial 6</li> <li>• Wiper volume dial 7</li> </ul>  <p style="text-align: right; font-size: small;">JP MIA0040GB</p> <p style="text-align: center;">1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch HI (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 2ND (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Rear washer switch ON (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMA0039GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions be- low with all switches OFF	 <p style="text-align: right; font-size: small;">JPMA0040GB</p> <p style="text-align: center;">1.3 V</p>
89 (SB)*2 (L)*4 (BR)*7	Ground	Push-button ignition switch (Push switch)	Input	Push-button ig- nition switch (push switch)	Pressed	0 V
				Not pressed	12 V	
90 (P)	Ground	CAN-L	Input/ Output	—	—	
91 (L)	Ground	CAN-H	Input/ Output	—	—	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	12 V
					Blinking	 6.5 V
					ON	0 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ON or ACC	0 V
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—	12 V	
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	12 V
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	12 V
					UNLOCK status	0 V
99 (GR)* <sup>8</sup> (R)* <sup>9</sup>	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	12 V
100 (G)* <sup>6</sup> (P)* <sup>7</sup>	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 1.0 V
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
103 (BR)* <sup>2</sup> (LG)* <sup>3</sup>	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF	12 V	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
105 (R)	Ground	Door lock status indicator lamp	Output	Door lock status indicator lamp	OFF	12 V
					ON	0 V
106 (W)	Ground	Steering lock unit power supply	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper volume dial 4)	All switches OFF	 1.4 V
					Turn signal switch LH	 1.3 V
					Turn signal switch RH	 1.3 V
					Front wiper switch LO	 1.3 V
					Front washer switch ON	 1.3 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW







# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch AUTO (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 1ST (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper switch INT (Wiper volume dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0040GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions be- low with all switches OFF	 <p style="text-align: right; font-size: small;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
109 (GR)*4 (Y)*5	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper volume dial 4)	All switches OFF	 <p style="text-align: right;">JPMA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch PASS	 <p style="text-align: right;">JPMA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 2ND	 <p style="text-align: right;">JPMA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch AUTO	 <p style="text-align: right;">JPMA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch HI	 <p style="text-align: right;">JPMA0040GB</p> <p style="text-align: center;">1.3 V</p>
					ON	0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch		
				OFF	 <p style="text-align: right;">JPMA0012GB</p> <p style="text-align: center;">1.1 V</p>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW




# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
111 (GR)*2 (Y)*3	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	12 V
					LOCK or UNLOCK	 <p style="text-align: right; font-size: small;">JMkia0066GB</p>
					For 15 seconds after UN- LOCK	12 V
					15 seconds or later after UNLOCK	0 V
112 (R)*10 (GR)*11	Ground	Light and rain sensor serial link	Input/ Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">JPMIA0156GB</p>	
113*12 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
				When dark outside of the vehicle	Close to 0 V	
114*13 (GR)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is not depressed)	0 V
					ON (Clutch pedal is de- pressed)	Battery voltage
115 (O)	Ground	Air bag signal	Input	Ignition switch	OFF	0 V
					ACC	5.0 V
					ON	 <p style="text-align: right; font-size: small;">JPMIA1034GB</p>
116 (BR)*2 (LG)*4 (SB)*7	Ground	Stop lamp switch 1	Input	—	Battery voltage	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
117 (Y)	Ground	Sensor cancel switch	Input	Sensor cancel switch	OFF (Not pressed)	 11.8 V
				ON (Pressed)	0 V	
118 (SB) <sup>*4</sup> (P) <sup>*5</sup>	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is depressed)	Battery voltage
		Stop lamp switch 2 (With ICC)		Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF	0 V	
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON	Battery voltage	
119 (SB) <sup>*6</sup> (L) <sup>*7</sup>	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 8.5 - 9.0 V
					UNLOCK status (Unlock switch sensor ON)	0 V
120 <sup>*13</sup> (O)	Ground	Back-up lamp switch	Input	Ignition switch ON	Control lever in reverse position	Battery voltage
					Control lever in any position other than reverse	0 V
121 (BR) <sup>*2</sup> (R) <sup>*4</sup> (LG) <sup>*7</sup>	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot	12 V	
				When the Intelligent Key is not inserted into key slot	0 V	
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 8.5 - 9.0 V
					ON (Door open)	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
132 (BR)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 <small>JPMIA0013GB</small> 10.2 V	
				Ignition switch OFF or ACC		12 V	
134 (V) <sup>*4</sup> (GR) <sup>*5</sup>	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage	
					ON	0 V	
137 (B) <sup>*2</sup> (BR) <sup>*4</sup> (G) <sup>*7</sup>	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V	
138 <sup>*12</sup> (Y)	Ground	Sensor power supply	Output	Ignition switch	OFF	0 V	
					ACC or ON	5 V	
140 (BR) <sup>*13</sup> (R) <sup>*14</sup> (G) <sup>*15</sup> (GR) <sup>*16</sup>	Ground	Selector lever P/N position (A/T models)	Input	Selector lever	P or N position	12 V	
					Except P and N positions		0 V
		Park/neutral position switch (M/T models)		Ignition switch ON	Control lever in neutral position	Battery voltage	
					Control lever in any posi- tion other than neutral		0 V
141 (G)	Ground	Security indicator lamp	Output	Security indica- tor lamp	ON	0 V	
					Blinking		 <small>JPMIA0014GB</small> 11.3 V
					OFF		12 V
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V	
					Lighting switch 1ST	 <small>JPMIA0031GB</small> 10.7 V	
					Lighting switch HI		
					Lighting switch 2ND		
					Turn signal switch RH		

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper volume dial 4)	0 V
					Front wiper switch HI (Wiper volume dial 4)	
					Rear wiper switch INT (Wiper volume dial 4)	
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper volume dial 1</li> <li>• Wiper volume dial 2</li> <li>• Wiper volume dial 3</li> <li>• Wiper volume dial 6</li> <li>• Wiper volume dial 7</li> </ul>	
10.7 V						
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper volume dial 4)	0 V
					Front washer switch ON (Wiper volume dial 4)	
					Rear wiper switch ON (Wiper volume dial 4)	
					Rear washer switch ON (Wiper volume dial 4)	
Any of the conditions below with all switches OFF <ul style="list-style-type: none"> <li>• Wiper volume dial 1</li> <li>• Wiper volume dial 5</li> <li>• Wiper volume dial 6</li> </ul>						
10.7 V						
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V
					Front wiper switch AUTO	
					Front wiper switch LO	
					Lighting switch AUTO	
Rear fog lamp switch ON						
10.7 V						
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
Turn signal switch LH						
10.7 V						

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	 <p style="text-align: center; font-size: small;">JPMIA0594GB 8.5 - 9.0 V</p>
				ON (Door open)	0 V	
151 (G)	Ground	Rear window defogger relay control	Output	Rear window defogger	Active	0 V
				Not activated	Battery voltage	

- \*1: Only RHD models
- \*2: LHD gasoline engine models
- \*3: Except LHD gasoline engine models
- \*4: LHD diesel engine models
- \*5: Except LHD diesel engine models
- \*6: LHD models
- \*7: RHD models
- \*8: RHD gasoline engine models
- \*9: Except RHD gasoline engine models
- \*10: RHD diesel engine models
- \*11: Except RHD diesel engine models
- \*12: For Russia
- \*13: M/T models
- \*14: LHD A/T gasoline engine models
- \*15: LHD A/T diesel engine models
- \*16: RHD A/T models



# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JCMWM7469GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWM7470GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - BCM (Diesel Engine Models) -

INFOID:000000006091557

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).




\*: This connector is not shown in "Harness Layout".

2010/01/25

JCMWM7473GB

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWM7474GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JCMWM7475GB



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JCMWM7477GB

## Fail-safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

INFOID:000000005406790

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2196: DONGLE NG	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals are received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter control relay signal</li> <li>• Starter relay status signal</li> </ul>
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> <li>• Selector lever P position switch signal</li> <li>• P range signal (CAN)</li> </ul>
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (12 V)</li> <li>• Vehicle speed: 4 km/h (2.5 MPH) or more</li> </ul>
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position</li> <li>• Selector lever P position switch signal: Except P position (12 V)</li> <li>• Selector lever P/N position signal: Except P and N positions (0 V)</li> </ul>
B2604: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P and N position (12 V)</li> <li>- P range signal or N range signal (CAN): ON</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- P range signal and N range signal (CAN): OFF</li> </ul> </li> </ul>
B2605: PNP/CLUTCH SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch is in the ON position <ul style="list-style-type: none"> <li>- Power position: IGN</li> <li>- Selector lever P/N position signal: Except P and N positions (0 V)</li> <li>- Interlock/PNP switch signal (CAN): OFF</li> </ul> </li> <li>• Status 2 <ul style="list-style-type: none"> <li>- Ignition switch is in the ON position</li> <li>- Selector lever P/N position signal: P or N position (12 V)</li> <li>- Interlock/PNP switch signal (CAN): ON</li> </ul> </li> </ul>
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Steering lock relay signal (Request signal)</li> <li>• Steering lock relay signal (Condition signal)</li> </ul>

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B2609: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When the following steering lock conditions agree <ul style="list-style-type: none"> <li>• BCM steering lock control status</li> <li>• Steering lock condition No. 1 signal status</li> <li>• Steering lock condition No. 2 signal status</li> </ul>
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> <li>• IGN relay (IPDM E/R) control signal: OFF (12 V)</li> <li>• Ignition ON signal (CAN to IPDM E/R): OFF (Request signal)</li> <li>• Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)</li> </ul>
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2612: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering lock unit status signal (CAN) is received normally</li> <li>• The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)</li> </ul>
B2617: BCM	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B261F: ASCD CNCL/CLTCH SW	Inhibit steering lock	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power supply position: ON</li> <li>• Receives clutch switch signal (CAN from ECM): OFF</li> </ul>
B2620: NEUTRAL SW	Inhibit engine cranking (Only when try to start the engine while depressing brake pedal and shifting to the neutral position)	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1               <ul style="list-style-type: none"> <li>- Back up lamp switch signal: ON (Battery voltage)</li> <li>- Park/neutral position switch signal: OFF (0 V)</li> </ul> </li> <li>• Status 2               <ul style="list-style-type: none"> <li>- Back-up lamp switch signal: OFF (0 V)</li> <li>- Park/neutral position switch signal: ON (Battery voltage)</li> </ul> </li> <li>• Status 3               <ul style="list-style-type: none"> <li>- Back-up lamp switch signal: OFF (0 V)</li> <li>- Park/neutral position switch signal: OFF (0 V)</li> </ul> </li> </ul>
B26E8: CLUTCH SW	Inhibit engine cranking	When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> <li>• Status 1               <ul style="list-style-type: none"> <li>- ASCD clutch switch signal (CAN from ECM): ON</li> <li>- Clutch interlock switch signal: OFF (0 V)</li> </ul> </li> <li>• Status 2               <ul style="list-style-type: none"> <li>- ASCD clutch switch signal (CAN from ECM): OFF</li> <li>- Clutch interlock switch signal: ON (Battery voltage)</li> </ul> </li> </ul>
B26E9: S/L STATUS	<ul style="list-style-type: none"> <li>• Inhibit engine cranking</li> <li>• Inhibit steering lock</li> </ul>	When BCM transmits the LOCK request signal to steering lock unit, and receives LOCK response signal from steering lock unit, the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Steering condition No. 1 signal: LOCK (0V)</li> <li>• Steering condition No. 2 signal: LOCK (12 V)</li> </ul>

#### FAIL-SAFE CONTROL BY LIGHT AND RAIN SENSOR MALFUNCTION

BCM detects the light and rain sensor serial link error and the light and rain sensor malfunction. BCM controls the following fail-safe when light and rain sensor has a malfunction.

##### Fail-safe Control

- Auto light control: Headlamp low beam, parking lamp, license plate lamp and tail lamp are turned ON.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

- Front wiper control
- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal. When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. More than 1 minute is passed after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### DTC Inspection Priority Chart

INFOID:000000005406791

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"><li>• U1000: CAN COMM</li><li>• U1010: CONTROL UNIT(CAN)</li></ul>
3	<ul style="list-style-type: none"><li>• B2190: NATS ANTENNA AMP</li><li>• B2191: DIFFERENCE OF KEY</li><li>• B2192: ID DISCORD BCM-ECM</li><li>• B2193: CHAIN OF BCM-ECM</li><li>• B2195: ANTI SCANNING</li><li>• B2196: DONGLE NG</li></ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS INFORMATION >

Priority	DTC
4	<ul style="list-style-type: none"> <li>• B2013: ID DISCORD BCM-S/L</li> <li>• B2014: CHAIN OF S/L-BCM</li> <li>• B2553: IGNITION RELAY</li> <li>• B2555: STOP LAMP</li> <li>• B2556: PUSH-BTN IGN SW</li> <li>• B2557: VEHICLE SPEED</li> <li>• B2560: STARTER CONT RELAY</li> <li>• B2601: SHIFT POSITION</li> <li>• B2602: SHIFT POSITION</li> <li>• B2603: SHIFT POSI STATUS</li> <li>• B2604: PNP/CLUTCH SW</li> <li>• B2605: PNP/CLUTCH SW</li> <li>• B2606: S/L RELAY</li> <li>• B2607: S/L RELAY</li> <li>• B2608: STARTER RELAY</li> <li>• B2609: S/L STATUS</li> <li>• B260A: IGNITION RELAY</li> <li>• B260B: STEERING LOCK UNIT</li> <li>• B260C: STEERING LOCK UNIT</li> <li>• B260D: STEERING LOCK UNIT</li> <li>• B260F: ENG STATE SIG LOST</li> <li>• B2612: S/L STATUS</li> <li>• B2614: BCM</li> <li>• B2615: BCM</li> <li>• B2616: BCM</li> <li>• B2617: BCM</li> <li>• B2618: BCM</li> <li>• B2619: BCM</li> <li>• B261A: PUSH-BTN IGN SW</li> <li>• B261E: VEHICLE TYPE</li> <li>• B261F: ASCD CNCL/CLTCH SW</li> <li>• B2620: NEUTRAL SW</li> <li>• B26E8: CLUTCH SW</li> <li>• B26E9: S/L STATUS</li> <li>• B26EA: KEY REGISTRATION</li> <li>• U0415: VEHICLE SPEED</li> </ul>
5	<ul style="list-style-type: none"> <li>• B2621: INSIDE ANTENNA</li> <li>• B2622: INSIDE ANTENNA</li> <li>• B2623: INSIDE ANTENNA</li> </ul>
6	B26E7: TPMS CAN COMM

## DTC Index

INFOID:000000005406792

### NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [WW-19, "COMMON ITEM : CONSULT-III Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference page
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	<a href="#">BCS-40</a>
U1010: CONTROL UNIT(CAN)	—	—	—	<a href="#">BCS-41</a>
U0415: VEHICLE SPEED	—	—	—	<a href="#">BCS-42</a>
B2013: ID DISCORD BCM-S/L	×	×	—	<a href="#">SEC-56</a>

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference page
B2014: CHAIN OF S/L-BCM	×	×	—	<a href="#">SEC-57</a>
B2190: NATS ANTENNA AMP	×	—	—	<a href="#">SEC-47</a>
B2191: DIFFERENCE OF KEY	×	—	—	<a href="#">SEC-50</a>
B2192: ID DISCORD BCM-ECM	×	—	—	<a href="#">SEC-51</a>
B2193: CHAIN OF BCM-ECM	×	—	—	<a href="#">SEC-52</a>
B2195: ANTI SCANNING	×	—	—	<a href="#">SEC-53</a>
B2196: DONGLE NG	×	—	—	<a href="#">SEC-54</a>
B2553: IGNITION RELAY	—	×	—	<a href="#">PCS-55</a>
B2555: STOP LAMP	—	×	—	<a href="#">SEC-60</a>
B2556: PUSH-BTN IGN SW	—	×	×	<a href="#">SEC-62</a>
B2557: VEHICLE SPEED	×	×	×	<a href="#">SEC-64</a>
B2560: STARTER CONT RELAY	×	×	×	<a href="#">SEC-65</a>
B2562: LOW VOLTAGE	—	×	—	<a href="#">BCS-43</a>
B2601: SHIFT POSITION	×	×	×	<a href="#">SEC-66</a>
B2602: SHIFT POSITION	×	×	×	<a href="#">SEC-69</a>
B2603: SHIFT POSI STATUS	×	×	×	<a href="#">SEC-71</a>
B2604: PNP/CLUTCH SW	×	×	×	<a href="#">SEC-74</a>
B2605: PNP/CLUTCH SW	×	×	×	<a href="#">SEC-76</a>
B2606: S/L RELAY	×	×	×	<a href="#">SEC-78</a>
B2607: S/L RELAY	×	×	×	<a href="#">SEC-79</a>
B2608: STARTER RELAY	×	×	×	<a href="#">SEC-81</a>
B2609: S/L STATUS	×	×	×	<a href="#">SEC-83</a>
B260A: IGNITION RELAY	×	×	×	<a href="#">PCS-57</a>
B260B: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-87</a>
B260C: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-88</a>
B260D: STEERING LOCK UNIT	—	×	×	<a href="#">SEC-89</a>
B260F: ENG STATE SIG LOST	×	×	×	<a href="#">SEC-90</a>
B2612: S/L STATUS	×	×	×	<a href="#">SEC-91</a>
B2614: BCM	—	×	×	<a href="#">PCS-59</a>
B2615: BCM	—	×	×	<a href="#">PCS-61</a>
B2616: BCM	—	×	×	<a href="#">PCS-63</a>
B2617: BCM	×	×	×	<a href="#">SEC-95</a>
B2618: BCM	×	×	×	<a href="#">PCS-65</a>
B2619: BCM	×	×	×	<a href="#">SEC-97</a>
B261A: PUSH-BTN IGN SW	—	×	×	<a href="#">PCS-66</a>
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	<a href="#">SEC-98</a>
B261F: ASCD CNCL/CLTCH SW	×	×	×	<a href="#">SEC-99</a>
B2620: NEUTRAL SW	×	×	×	<a href="#">SEC-101</a>
B2621: INSIDE ANTENNA	—	×	—	<a href="#">DLK-68*1</a> <a href="#">DLK-326*2</a>
B2622: INSIDE ANTENNA	—	×	—	<a href="#">DLK-70*1</a> <a href="#">DLK-328*2</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference page
B2623: INSIDE ANTENNA	—	×	—	<a href="#">DLK-72</a> *1 <a href="#">DLK-330</a> *2
B26E7: TPMS CAN COMM	—	—	—	<a href="#">BCS-44</a>
B26E8: CLUTCH SW	×	×	×	<a href="#">SEC-104</a>
B26E9: S/L STATUS	×	×	× (Turn ON for 15 seconds)	<a href="#">SEC-106</a>
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	<a href="#">SEC-107</a>

- \*1: With super lock
- \*2: Without super lock

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000005406795

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 – 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (light is illuminated)		On
	Daytime running light system is operated		
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	Off
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch AUTO	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N (A/T models)	Off
		Release clutch pedal (M/T models)	
		Selector lever in P or N position (A/T models)	On
		Depress clutch pedal (M/T models)	
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


## < ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
IHBT RLY -REQ	Ignition switch ON	Off
	At engine cranking	On
ST/INHI RLY	Ignition switch ON	Off
	At engine cranking	INHI → ST
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN
DETENT SW	Ignition switch ON <ul style="list-style-type: none"> <li>• Press the selector button with selector lever in P position</li> <li>• Selector lever in any position other than P</li> </ul>	Off
	Release the selector button with selector lever in P position <b>NOTE:</b> Fixed On for M/T models	On
S/L RLY -REQ	None of the conditions below are present	Off
	<ul style="list-style-type: none"> <li>• Open the driver door after the ignition switch is turned OFF (for a few seconds)</li> <li>• Press the push-button ignition switch when the steering lock is activated</li> </ul>	On
S/L STATE	Steering lock is activated	LOCK
	Steering lock is deactivated	UNLOCK
	[DTC: B210A] is detected	UNKWN
DTRL REQ <b>NOTE:</b> This item is monitored only on the vehicle with the daytime running light system.	Daytime running light system is not operated with ignition switch OFF	Off
	Any of the condition below <ul style="list-style-type: none"> <li>• Daytime running light system is operated</li> <li>• Light switch 1ST, 2ND or AUTO (light is illuminated)</li> </ul>	On
OIL P SW	Ignition switch OFF, ACC or engine running	Open
	Ignition switch ON	Close
HOOD SW	Close the hood	Off
	Open the hood	On
HL WASHER REQ	Not operating	Off
	Headlamp washer operating	On
THFT HRN REQ	Not operation	Off
	<ul style="list-style-type: none"> <li>• Panic alarm is activated</li> <li>• Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM</li> </ul>	On
HORN CHIRP	<b>NOTE:</b> The item is indicated, but not monitored.	Off
CRNRNG LMP REQ	<b>NOTE:</b> The item is indicated, but not monitored.	Off

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
4 (V)	Ground	Front wiper LO	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch HI	Battery voltage
6*1 (SB)	Ground	Daytime running light relay	Input	Ignition switch OFF		Battery voltage
7 (R)	Ground	Illuminations*1 Tail, license plate lamps & illuminations*2	Output	Ignition switch ON	Lighting switch OFF	0 V
					Lighting switch 1ST	Battery voltage
10 (P)*8 (SB)*11 (O)*13	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
11 (BR)	Ground	Steering lock unit power supply	Output	Ignition switch OFF	A few seconds after opening the driver door	Battery voltage
				Ignition switch LOCK	Press the push-button ignition switch	Battery voltage
						0 V
12 (B)*7 (B/W)*8	Ground	Ground	—	Ignition switch ON		0 V
13 (Y)*7 (GR)*8	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V
				<ul style="list-style-type: none"> <li>• Approximately 1 second after turning the ignition switch ON</li> <li>• Engine running</li> </ul>		Battery voltage
15 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
16 (LG)	Ground	Front wiper stop position	Input	Ignition switch ON	Front wiper stop position	0 V
					Any position other than front wiper stop position	Battery voltage
17 (G)	Ground	Headlamp washer relay control	Output	Ignition switch ON	Headlamp washer deactivated	Battery voltage
					Headlamp washer activated	0 V
19*7 (W)*3 (V)*4	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
26 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
27 (Y)*3 (LG)*4	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC		Battery voltage
				Ignition switch ON		0 V
28 (O)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch		0 V
				Release the push-button ignition switch		Battery voltage
30 (GR)*5 (V)*6	Ground	Starter relay control	Input	A/T models	Selector lever in any position other than P or N	0 V
					Selector lever P or N	Battery voltage
				M/T models	Release the clutch pedal	0 V
					Depress the clutch pedal	Battery voltage
32 (SB)	Ground	Steering lock unit condition-1	Input	Steering lock is activated		0 V
				Steering lock is deactivated		Battery voltage
33 (P)	Ground	Steering lock unit condition-2	Input	Steering lock is activated		Battery voltage
				Steering lock is deactivated		0 V
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
39 (P)	—	CAN-L	Input/ Output	—		—

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
40 (L)	—	CAN-H	Input/ Output	—	—	A
41 (B)*7 (B/W)*8	Ground	Ground	—	Ignition switch ON	0 V	B
42 (Y)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC	0 V	C
				Ignition switch ON	0.7 V	D
43 (SB)*11 (W)*12 (G)*13 (R)*14	Ground	A/T shift selector (Detention switch)	Input	Ignition switch ON	Battery voltage	E
				Release the selector button (selector lever P)	0 V	F
44 (W)*7 (BR)*8	Ground	Horn relay control	Input	The horn is deactivated	Battery voltage	F
				The horn is activated	0 V	G
46 (BR)*11 (LG)*12 (R)*13 (SB)*14	Ground	Starter relay control	Input	Ignition switch ON	0 V	H
				Selector lever P or N	Battery voltage	I
48 (L)	Ground	A/C relay power supply	Output	Engine running	0 V	J
				A/C switch ON (A/C compressor is operating)	Battery voltage	K
49 (G)*8 (W)*16 (O)*17 (SB)*22	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	L
				Ignition switch ON Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage	M
51 (SB)*8 (G)*11 (P)*13	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	N
				Ignition switch ON	Battery voltage	O
52*7 (W)*3 (R)*4	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	P
				Ignition switch ON	Battery voltage	Q
53 (V)*8 (W)*11 (SB)*17 (Y)*18	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	R
				Ignition switch ON Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage	S
54*7 (R)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V	T
				Ignition switch ON Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage	U




# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
55 (BR)	Ground	ECM power supply	Output	Ignition switch OFF	Battery voltage
56*7 (V)*9 (O)*10	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
57 (LG)*7 (O)*8	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
58 (V)*6 (GR)*23 (Y)*24	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
69 (W)*7 (L)*8	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	Battery voltage
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>	0 – 1.5 V
70 (O)*7 (B/W)*8	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF	0 – 1.0 V ↓ Battery voltage ↓ 0 V
				Ignition switch ON	0 – 1.0 V
73*8 (P)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
74*7 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V
				Ignition switch ON	Battery voltage
75 (Y)*7 (SB)*8	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped 0 V
				Engine running	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
76 (V)*21 (P)*19	Ground	Power generation command signal	Output	Ignition switch ON	 <p>6.3 V</p>
				40% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"	 <p>3.8 V</p>
				80% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"	 <p>1.4 V</p>
77 (GR)*8 (B)*10 (L)*15 (R)*17	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>	0 - 1.0 V
				Approximately 1 second or more after turning the ignition switch ON	Battery voltage
80 (W)	Ground	Starter motor	Output	At engine cranking	Battery voltage
83 (R)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch OFF: 0 V</li> <li>Lighting switch 2ND: Battery voltage</li> </ul>
				Daytime running light operated	Battery voltage
84 (P)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch OFF: 0 V</li> <li>Lighting switch 2ND: Battery voltage</li> </ul>
				Daytime running light operated	Battery voltage
86 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON: Battery voltage</li> <li>Front fog lamp switch OFF: 0 V</li> </ul>
				Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON: Battery voltage</li> <li>Front fog lamp switch OFF: 0 V</li> </ul>
87 (GR)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON: Battery voltage</li> <li>Front fog lamp switch OFF: 0 V</li> </ul>
				Lighting switch 2ND	<ul style="list-style-type: none"> <li>Front fog lamp switch ON: Battery voltage</li> <li>Front fog lamp switch OFF: 0 V</li> </ul>
88 (G)	Ground	Washer pump power supply	Output	Ignition switch ON	Battery voltage
89 (BR)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch HI: Battery voltage</li> <li>Lighting switch PASS: Battery voltage</li> </ul>
				Lighting switch OFF	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
90 (Y)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	<ul style="list-style-type: none"> <li>Lighting switch HI</li> <li>Lighting switch PASS</li> </ul>	Battery voltage
				Lighting switch OFF		0 V
91 (P)	Ground	Parking (RH), tail, li- cense plate lamps*1	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
		Parking lamp (RH)*2			Lighting switch OFF	0 V
92 (O)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
					Lighting switch OFF	0 V
97 (G)*12 (V)*20	Ground	Cooling fan control	Output	Engine idling		0 – 5 V
104 (LG)	Ground	Hood switch	Input	Close the hood		Battery voltage
				Open the hood		0 V
105*1 (V)	Ground	Daytime running light relay control	Output	<ul style="list-style-type: none"> <li>Parking lamp</li> <li>License plate lamp</li> <li>Tail lamp</li> </ul>	Turned OFF	Battery voltage
					Turned ON	0 V

\*1: With daytime running light system

\*2: Without daytime running light system

\*3: LHD models

\*4: RHD models

\*5: A/T models

\*6: M/T models

\*7: Gasoline engine models

\*8: Diesel engine models

\*9: VQ engine models

\*10: VK engine models

\*11: LHD models with gasoline engine

\*12: LHD models with diesel engine

\*13: RHD models with gasoline engine

\*14: RHD models with diesel engine

\*15: LHD models with VQ engine

\*16: LHD models with VK engine

\*17: RHD models with VQ engine

\*18: RHD models with VK engine

\*19: Except for LHD models with VQ engine or diesel engine

\*20: Except for LHD models with diesel engine

\*21: LHD models with VQ engine or diesel engine

\*22: LHD models with VQ engine and RHD models with VK engine

\*23: RHD models with A/T and gasoline engine

\*24: With A/T except RHD models with gasoline engine


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - IPDM E/R (Gasoline Engine) -

INFOID:000000005406796

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



2010/01/25


JCMWM7491GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >



JCMWM7492GB


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

---

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

IPDM E/R  
(INTELLIGENT POWER  
DISTRIBUTION MODULE  
ENGINE ROOM)  
E4 . E5 . E6 .  
E7 . E8 . E9 .



WW

JCMWM7493GB


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - IPDM E/R (Diesel Engine) -

INFOID:000000006113702

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).




2010/01/25

JCMWM7494GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >



JCMWM7495GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WW

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

---



JCMWM7496GB

INFOID:000000005406797

## Fail-safe

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>• Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>• Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

### If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Illuminations</li> <li>• Tail lamps</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay and the daytime running light relay* when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay and the daytime running light relay* when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the AUTO mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF
Steering lock unit	Steering lock relay OFF
Headlamp washer relay	Headlamp washer relay OFF

\*: With daytime running light system

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay and the daytime running light relay\* for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>• Detects DTC "B2098: IGN RELAY ON"</li> <li>• Turns ON the tail lamp relay and the daytime running light relay* for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC "B2099: IGN RELAY OFF"

\*: With daytime running light system

### FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS INFORMATION >

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

### DTC Index

INFOID:000000005406798

### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

CONSULT display	Fail-safe	Reference
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-18</a>
B2098: IGN RELAY ON	×	<a href="#">PCS-19</a>
B2099: IGN RELAY OFF	—	<a href="#">PCS-20</a>
B2108: STRG LCK RELAY ON	—	<a href="#">SEC-108</a>
B2109: STRG LCK RELAY OFF	—	<a href="#">SEC-110</a>
B210A: STRG LCK STATE SW	—	<a href="#">SEC-111</a>
B210B: START CONT RLY ON	—	<a href="#">SEC-115</a>
B210C: START CONT RLY OFF	—	<a href="#">SEC-116</a>
B210D: STARTER RELAY ON	—	<a href="#">SEC-117</a>
B210E: STARTER RELAY OFF	—	<a href="#">SEC-118</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-120</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-123</a>

# WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### WIPER AND WASHER SYSTEM SYMPTOMS FOR EUROPE

FOR EUROPE : Symptom Table

INFOID:000000005370237

**CAUTION:**

Perform the self-diagnosis with CONSULT-III before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

Symptom		Probable malfunction location	Inspection item
Front wiper does not operate.	HI only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>	Front wiper motor (HI) circuit Refer to <a href="#">WW-30, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	LO only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Harness between IPDM E/R and front wiper motor</li> <li>Front wiper motor</li> </ul>	Front wiper motor (LO) circuit Refer to <a href="#">WW-28, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>BCM</li> <li>IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	AUTO only	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>Light &amp; rain sensor</li> <li>Harness between light &amp; rain sensor and BCM</li> <li>BCM</li> </ul>	Light & rain sensor Refer to <a href="#">WW-36, "Component Function Check"</a> .
	HI, LO and AUTO	SYMPTOM DIAGNOSIS "FRONT WIPER DOES NOT OPERATE" Refer to <a href="#">WW-119, "Diagnosis Procedure"</a> .	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## WIPER AND WASHER SYSTEM SYMPTOMS

### < SYMPTOM DIAGNOSIS >

Symptom	Probable malfunction location	Inspection item	
Front wiper does not stop.	HI only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>Front wiper request signal</li> <li>• BCM</li> <li>• IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
	LO only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>Front wiper request signal</li> <li>• BCM</li> <li>• IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
	AUTO only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• Light &amp; rain sensor</li> <li>• Harness between light &amp; rain sensor and BCM</li> <li>• BCM</li> </ul>	Light & rain sensor Refer to <a href="#">WW-36, "Component Function Check"</a> .
	Front wiper does not operate normally.	Sensitivity adjustment cannot be performed.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>
BCM			—
Wiper is not linked to the washer operation.		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		BCM	—
Does not return to stop position [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)]		<ul style="list-style-type: none"> <li>• IPDM E/R</li> <li>• Harness between IPDM E/R and front wiper motor</li> <li>• Front wiper motor</li> </ul>	Front wiper auto stop signal circuit Refer to <a href="#">WW-32, "Component Function Check"</a> .
Rear wiper does not operate.		ON only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>
	INT only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
	ON and INT	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• BCM</li> <li>• Harness between rear wiper motor and BCM</li> <li>• Harness between rear wiper motor and ground</li> <li>• Rear wiper motor</li> </ul>	Rear wiper motor circuit Refer to <a href="#">WW-38, "Component Function Check"</a> .
Rear wiper does not stop.	ON only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Rear wiper motor circuit Refer to <a href="#">WW-38, "Component Function Check"</a> .
	INT only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .

# WIPER AND WASHER SYSTEM SYMPTOMS

## < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Rear wiper does not operate normally.	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between rear wiper motor and BCM</li> <li>BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91</a> . "Symptom Table".
		BCM	—
	Rear wiper does not return to the stop position [Stops after a five-second operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>BCM</li> <li>Harness between rear wiper motor and BCM</li> <li>Rear wiper motor</li> </ul>	Rear wiper auto stop signal circuit Refer to <a href="#">WW-40</a> . "Component Function Check".
	Rear wiper does not operate even when selector lever is shifted to the "R". (AT models)	Shift position signal (CAN communication) <ul style="list-style-type: none"> <li>BCM</li> <li>TCM</li> </ul>	TCM DATA MONITOR "SLCT LVR POSI"
Rear wiper does not operate even when shift lever is shifted to the "R". (MT models)	Back-up lamp switch signal <ul style="list-style-type: none"> <li>BCM</li> <li>Back-up lamp switch</li> </ul>	Back-up lamp switch Refer to <a href="#">TM-14</a> . "Component Inspection".	
Headlamp washer does not operate.	Headlamp washer does not operate with the front washer when headlamps are turned ON.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> <li>Headlamp washer pump</li> </ul>	Combination switch Refer to <a href="#">BCS-91</a> . "Symptom Table".
		<ul style="list-style-type: none"> <li>Fusible link</li> <li>Harness between fusible link and headlamp washer relay</li> <li>Headlamp washer relay</li> <li>Harness between headlamp washer relay and IPDM E/R</li> <li>IPDM E/R</li> <li>Harness between headlamp washer relay and headlamp washer pump</li> <li>Harness between headlamp washer pump and ground</li> <li>Headlamp washer pump</li> </ul>	Headlamp washer circuit Refer to <a href="#">WW-45</a> . "Component Function Check".
	BCM	—	

FOR RUSSIA

FOR RUSSIA : Symptom Table

INFOID:000000006054694

WW

### CAUTION:

Perform the self-diagnosis with CONSULT-III before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

## WIPER AND WASHER SYSTEM SYMPTOMS

### < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Front wiper does not operate.	HI only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• IPDM E/R</li> <li>• Harness between IPDM E/R and front wiper motor</li> <li>• Front wiper motor</li> </ul>	Front wiper motor (HI) circuit Refer to <a href="#">WW-30, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	LO and AUTO	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• IPDM E/R</li> <li>• Harness between IPDM E/R and front wiper motor</li> <li>• Front wiper motor</li> </ul>	Front wiper motor (LO) circuit Refer to <a href="#">WW-28, "Component Function Check"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
	AUTO only (Auto operation)	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• Light &amp;rain sensor</li> <li>• Harness between light &amp; rain sensor and BCM</li> <li>• BCM</li> </ul>	Light &rain sensor Refer to <a href="#">WW-36, "Component Function Check"</a> .
	HI, LO and AUTO	SYMPTOM DIAGNOSIS "FRONT WIPER DOES NOT OPERATE" Refer to <a href="#">WW-119, "Diagnosis Procedure"</a> .	
	Front wiper does not stop.	HI only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>
Front wiper request signal <ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>			IPDM E/R DATA MONITOR "FR WIP REQ"
IPDM E/R			—
LO only		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		Front wiper request signal <ul style="list-style-type: none"> <li>• BCM</li> <li>• IPDM E/R</li> </ul>	IPDM E/R DATA MONITOR "FR WIP REQ"
		IPDM E/R	—
AUTO only (Auto operation)		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• Light &amp;rain sensor</li> <li>• Harness between light &amp; rain sensor and BCM</li> <li>• BCM</li> </ul>	Light &rain sensor Refer to <a href="#">WW-36, "Component Function Check"</a> .

## WIPER AND WASHER SYSTEM SYMPTOMS

### < SYMPTOM DIAGNOSIS >

Symptom	Probable malfunction location	Inspection item
Front wiper does not operate normally.	Sensitivity adjustment cannot be performed.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		BCM —
	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		BCM —
	Does not return to stop position. [Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>• IPDM E/R</li> <li>• Harness between IPDM E/R and front wiper motor</li> <li>• Front wiper motor</li> </ul> Front wiper auto stop signal circuit Refer to <a href="#">WW-32, "Component Function Check"</a> .
	Rear wiper does not operate.	ON only
INT only		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
ON and INT		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		<ul style="list-style-type: none"> <li>• BCM</li> <li>• Harness between rear wiper motor and BCM</li> <li>• Harness between rear wiper motor and ground</li> <li>• Rear wiper motor</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
Rear wiper does not stop.	ON only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul> Rear wiper motor circuit Refer to <a href="#">WW-38, "Component Function Check"</a> .
	INT only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
Rear wiper does not operate normally.	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between rear wiper motor and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-91, "Symptom Table"</a> .
		BCM —
	Rear wiper does not return to the stop position. [Stops after a five-second operation. (Fail-safe)]	<ul style="list-style-type: none"> <li>• BCM</li> <li>• Harness between rear wiper motor and BCM</li> <li>• Rear wiper motor</li> </ul> Rear wiper auto stop signal circuit Refer to <a href="#">WW-40, "Component Function Check"</a> .
	Rear wiper does not operate even when selector lever is shifted to the "R".	Shift position signal (CAN communication) <ul style="list-style-type: none"> <li>• BCM</li> <li>• TCM</li> </ul> TCM DATA MONITOR "SLCT LVR POS"

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

---

### NORMAL OPERATING CONDITION

#### Description

INFOID:000000004965919

#### FRONT WIPER MOTOR PROTECTION FUNCTION

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

#### REAR WIPER MOTOR PROTECTION FUNCTION

- BCM may stop rear wiper to protect the rear wiper motor when the rear wiper is stopped for 5 seconds or more due to a snowfall.
- Rear wiper operates normally one minute after the obstacles are removed with rear wiper OFF.

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT WIPER DOES NOT OPERATE

### Description

INFOID:000000005370238

The front wiper does not operate under any operating conditions.

### Diagnosis Procedure

INFOID:000000005370239

#### 1. CHECK WIPER RELAY OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-13, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO/Hi operation.

##### Ⓜ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. With operating the test item, check that front wiper LO/Hi operation and OFF.

**Lo** : Front wiper LO operation

**Hi** : Front wiper HI operation

**Off** : Stop the front wiper.

##### Does the front wiper operate?

- YES >> GO TO 5.  
NO >> GO TO 2.

#### 2. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the front wiper motor 30A (#60) fuse is not fusing.

##### Is the fuse fusing?

- YES >> Replace the fuse after repairing the applicable circuit.  
NO >> GO TO 3.

#### 3. CHECK FRONT WIPER MOTOR (GND) OPEN CIRCUIT

Check front wiper motor (GND) open circuit. Refer to [WW-34, "Diagnosis Procedure"](#).

##### Does continuity exist?

- YES >> GO TO 4.  
NO >> Repair the harnesses or connectors.

#### 4. CHECK FRONT WIPER MOTOR OUTPUT VOLTAGE

##### Ⓜ CONSULT-III ACTIVE TEST

1. Disconnect front wiper motor connector.
2. Turn the ignition switch ON.
3. Select "FRONT WIPER" of IPDM E/R active test item.
4. With operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Approx.)		
(+)	(-)				
IPDM E/R		FRONT WIPER			
Connector	Terminal				
E5	4			Lo	Battery voltage
	5			Off	0 V
Ground		Hi	Battery voltage		
		Off	0 V		

##### Is the measurement normal?

- YES >> Replace front wiper motor.  
NO >> Replace IPDM E/R.

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## 5. CHECK FRONT WIPER REQUEST SIGNAL INPUT

---

### ④ CONSULT-III DATA MONITOR

1. Select "FR WIP REQ" of IPDM E/R data monitor item.
2. Switch the front wiper switch to HI and LO.
3. With operating the front wiper switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR WIPER REQ	Front wiper switch HI	ON	Hi
		OFF	Stop
	Front wiper switch LO	ON	Low
		OFF	Stop

Is the status of item normal?

- YES >> Replace IPDM E/R.  
NO >> GO TO 6.

## 6. CHECK COMBINATION SWITCH

---

Perform the inspection of the combination switch. Refer to [BCS-91. "Symptom Table"](#).

Is combination switch normal?

- YES >> Replace BCM. Refer to [BCS-94. "Exploded View"](#).  
NO >> Repair or replace the applicable parts.

# HEADLAMP WASHER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## HEADLAMP WASHER DOES NOT OPERATE FOR RUSSIA

### FOR RUSSIA : Description

INFOID:0000000006062123

Headlamp washer does not operate with headlamp washer switch nor is linked to front washer operation.

### FOR RUSSIA : Diagnosis Procedure

INFOID:0000000006062124

#### 1.CHECK HEADLAMP WASHER CIRCUIT

Check headlamp washer circuit. Refer to [WW-45, "Component Function Check"](#).

Is headlamp washer circuit normal?

YES >> GO TO 2.

NO >> Repair or replace the applicable parts.

#### 2.CHECK HEADLAMP WASHER SWITCH

Check headlamp washer switch. Refer to [WW-43, "Component Function Check"](#).

Is headlamp washer circuit normal?

YES >> GO TO 3.

NO >> Repair or replace the applicable parts.

#### 3.CHECK HEADLAMP WASHER REQUEST SIGNAL INPUT

##### ⓂCONSULT-III DATA MONITOR

1. Turn the lighting switch to 2ND.
2. Select "HL WASHER REQ" of IPDM E/R data monitor item.
3. With operating the headlamp washer switch, check the status of "HL WASHER REQ".

Monitor item	Condition		Monitor status
HL WASHER REQ	Headlamp washer switch	While pressing	On
		While not pressing	Off

Is the status of item normal?

YES >> Replace IPDM E/R.

NO >> Replace BCM. Refer to [BCS-94, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS FOR RUSSIA

#### FOR RUSSIA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006133910

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### FOR RUSSIA : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000006133911

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

# PRECAUTIONS


## < PRECAUTION >

- When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
- Perform self-diagnosis check of all control units using CONSULT-III.

### FOR RUSSIA : Precaution for Procedure without Cowl Top Cover

INFOID:000000006133916

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### EXCEPT FOR RUSSIA

### EXCEPT FOR RUSSIA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006134181

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### EXCEPT FOR RUSSIA : Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000006133914

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

# PRECAUTIONS

## < PRECAUTION >

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

### OPERATION PROCEDURE

1. Connect both battery cables.

**NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

### EXCEPT FOR RUSSIA : Precaution for Battery Service (for V9X Models)


INFOID:000000006133915

When disconnect the battery cable, pay attention to the following.

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- **Before disconnecting battery cables, turn ignition switch OFF and wait at least 4 minutes.**
- **After high-load driving, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery cable.**

**NOTE:**


Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.



### EXCEPT FOR RUSSIA : Precaution for Procedure without Cowl Top Cover

INFOID:000000006133917

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



# HEADLAMP WASHER NOZZLE AND TUBE


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### HEADLAMP WASHER NOZZLE AND TUBE

Exploded View


INFOID:000000004965926



- 1. Headlamp washer nozzle cover
- 2. Headlamp washer nozzle assembly
- 3. Headlamp washer nozzle bracket
- 4. Headlamp washer nozzle retainer

Hydraulic Layout

INFOID:000000004965927



- 1. Headlamp washer nozzle assembly (LH)
  - 2. Headlamp washer tube
  - 3. Headlamp washer nozzle assembly (RH)
  - A. Headlamp washer tube joint
- △ : Clip

Removal and Installation

INFOID:000000004965928


REMOVAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# HEADLAMP WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >

1. Pull out the headlamp washer nozzle from the bumper, disengage pawl (A), and remove the headlamp washer nozzle cover (1).
2. Remove the front bumper fascia. Refer to [EXT-15. "Exploded View"](#).
3. Disconnect the headlamp washer tube joint.
4. Remove the headlamp washer nozzle retainer.
5. Remove the headlamp washer nozzle bracket.
6. Remove the headlamp washer nozzle from the front bumper fascia.



## INSTALLATION


Install in the reverse order of removal.

## Inspection


INFOID:000000004965929

## HEADLAMP WASHER NOZZLE SPRAY POSITION INSPECTION

- Check that the headlamp washer injection is certainly on the headlamp illuminating area.



- Check the headlamp washer tube and headlamp washer nozzle leakages.
- Check the headlamp washer nozzle spray angle.



1. Headlamp washer nozzle (outside)
2. Headlamp washer nozzle (inside)

### Outside (A)

- a :  $0^\circ \pm 3^\circ$
- b :  $60^\circ \pm 3^\circ$

### Inside (B)

- c :  $60^\circ \pm 3^\circ$
- d :  $5^\circ \pm 3^\circ$

# HEADLAMP WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

---

**NOTE:**

This drawing shows the parts of the headlamp washer nozzle (LH). The headlamp washer nozzle (RH) is symmetrical of this drawing.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P


# WASHER TANK

< REMOVAL AND INSTALLATION >

## WASHER TANK

### Exploded View

INFOID:000000004965930



1. Washer tank inlet

2. Washer tank

### Removal and Installation


INFOID:000000004965931

#### REMOVAL

1. Remove the engine room cover RH (for VK50VE engine). Refer to [EM-174, "Exploded View"](#).
2. Remove the clip (A).

↔ : Vehicle front

3. Pull out the washer tank inlet (1) from the washer tank.
4. Remove the front bumper fascia. Refer to [EXT-15, "Exploded View"](#).
5. Disconnect the washer pump connector.
6. Disconnect the headlamp washer pump connector.
7. Disconnect the washer level switch connector.
8. Disconnect the front washer tube and rear washer tube.
9. Disconnect the headlamp washer tube joint.
10. Remove the washer tank mounting bolts.
11. Remove the washer tank from the vehicle.



#### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Add water up to the top of the washer tank inlet after installing. Check that there is no leakage.**


# WASHER PUMP

< REMOVAL AND INSTALLATION >

## WASHER PUMP

Exploded View

INFOID:000000004965932



- |                          |                     |                |
|--------------------------|---------------------|----------------|
| 1. Washer pump connector | 2. Rear washer tube | 3. Washer pump |
| 4. Front washer tube     | 5. Packing          | 6. Washer tank |

⇨ : Vehicle front

## Removal and Installation

INFOID:000000004965933

### REMOVAL

1. Remove the fender protector RH (front). Refer to [EXT-28, "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect the washer pump connector.
3. Disconnect the front washer tube and rear washer tube.
4. Remove the washer pump from the washer tank.
5. Remove the packing from the washer tank.

### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Never twist the packing when installing the washer pump.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


# HEADLAMP WASHER PUMP

< REMOVAL AND INSTALLATION >

## HEADLAMP WASHER PUMP

Exploded View

INFOID:000000004965934



1. Washer tank
2. Headlamp washer pump connector
3. Headlamp washer pump
4. Packing

## Removal and Installation

INFOID:000000004965935

### REMOVAL

1. Remove the fender protector RH (front). Refer to [EXT-28, "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect the headlamp washer pump connector.
3. Disconnect the headlamp washer tube joint.
4. Remove the headlamp washer pump from the washer tank.
5. Remove the packing from the washer tank.

### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Never twist the packing when installing the washer pump.**

# WASHER LEVEL SWITCH

< REMOVAL AND INSTALLATION >

## WASHER LEVEL SWITCH

---

### Removal and Installation

INFOID:000000004965936

The washer level switch must be replaced together with the washer tank as an assembly. Refer to [WW-128](#), "[Removal and Installation](#)".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


# FRONT WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

## FRONT WASHER NOZZLE AND TUBE

Hydraulic Layout

INFOID:000000004965937



- 1. Front washer tube
- 2. Front washer nozzle
- 3. Front washer tube
- 4. Washer tank


 : Clip A  
 : Clip B

## Removal and Installation

INFOID:000000005405081

### REMOVAL

1. Open the hood.
2. Use the stop point of washer nozzle (1) as the support point and rotate nozzle to remove it from body, while pushing nozzle spray point side along the hood.
3. Disconnect the washer tube (2) from the washer nozzle.



### INSTALLATION

1. Connect the washer tube into the washer nozzle.
2. Install the washer nozzle to the hood.
3. Adjust the washer nozzle spray position. Refer to [WW-132, "Inspection and Adjustment"](#).

#### **CAUTION:**

**The spray positions differ. Check that left and right nozzles are installed correctly.**

## Inspection and Adjustment

INFOID:000000005405082


### INSPECTION

Washer Nozzle Inspection

# FRONT WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >


Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



## ADJUSTMENT

### Washer Nozzle Spray Position Adjustment

Adjust spray positions to match the positions shown in the figure.



1. Black printed frame line

: Spray area

: Target spray position

Unit: mm (in)

Spray position	H	L	X	Y	S
A	204 (8.03)	486 (19.13)	80 (3.15)	226 (8.90)	79 (3.11)
B	274 (10.79)	358 (14.09)	80 (3.15)	319 (12.56)	99 (3.90)
C	274 (10.79)	124 (4.88)	80 (3.15)	332 (13.07)	96 (3.78)
D	269 (10.59)	126 (4.96)	80 (3.15)	304 (11.97)	93 (3.66)
E	298 (11.73)	253 (9.96)	80 (3.15)	332 (13.07)	94 (3.70)
F	239 (9.41)	466 (18.35)	80 (3.15)	295 (11.61)	91 (3.58)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


## FRONT WASHER NOZZLE AND TUBE

### < REMOVAL AND INSTALLATION >

Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

**NOTE:**

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.




# FRONT WIPER ARM

< REMOVAL AND INSTALLATION >

## FRONT WIPER ARM

Exploded View

INFOID:000000004965940



- 1. Front wiper blade (RH)
- 2. Front wiper arm (RH)
- 3. Front wiper blade (LH)
- 4. Front wiper arm (LH)
- 5. Front wiper arm cap

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation


INFOID:000000004965941

### REMOVAL

1. Operate the front wiper to move it to the auto stop position.
2. Open the hood.
3. Remove the front wiper arm caps.
4. Remove the front wiper arm mounting nuts.
5. Raise front wiper arm, and remove front wiper arm from the vehicle.

### INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nuts from being loosened.
2. Operate the front wiper motor to move the front wiper to the auto stop position.
3. Adjust the front wiper blade position. Refer to [WW-135, "Adjustment"](#).
4. Install the front wiper arm by tightening the mounting nuts.
5. Inject the washer fluid.
6. Operate the front wiper to move it to the auto stop position.
7. Check that the front wiper blades stop at the specified position.
8. Install the front wiper arm caps.



## Adjustment

INFOID:000000004965942

### WIPER BLADE POSITION ADJUSTMENT

Clearance between the end of cowl top cover and the top of wiper blade center


# FRONT WIPER ARM

## < REMOVAL AND INSTALLATION >

Standard clearance

**Passenger side (A) :  $72.2 \pm 7.5$  mm ( $2.843 \pm 0.295$  in)**

**Driver side (B) :  $60.6 \pm 7.5$  mm ( $2.386 \pm 0.295$  in)**




# WIPER BLADE

< REMOVAL AND INSTALLATION >

## WIPER BLADE

Exploded View

INFOID:000000005405075



- |                    |                    |              |
|--------------------|--------------------|--------------|
| 1. Wiper refill    | 2. Wiper blade     | 3. Wiper arm |
| A. Wiper blade end | B. Wiper blade tip |              |

## Removal and Installation

INFOID:000000005405076

### REMOVAL

Remove the wiper blade from the wiper arm.


### INSTALLATION

Install the front wiper blade to the wiper arm.

## Replacement

INFOID:000000005405077

1. Hold the rip of old wiper refill (1) at the rear end of the wiper blade with long-nose pliers, and pull out the wiper refill to the direction (A).




2. Insert the tip of new wiper refill (1) into the rear end of wiper blade. Slide the wiper refill to the direction (A) while pressing the wiper refill onto the wiper blade rear end.

### NOTE:

- Insert the wiper refill to be held securely by tab (B) of wiper blade.
- After the wiper refill is fully inserted, remove the holder\* (2).

\*: Attached to service parts.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW

## WIPER BLADE



### < REMOVAL AND INSTALLATION >

3. Inert the wiper refill until the stopper at the rear end of wiper refill fits in the tab. Check that "LOCK" mark on wiper refill is aligned with "▼" mark on wiper blade.
4. Untwist the twisted wiper refill (▨) at the rear end of wiper blade, if any.
5. Check the following items after replacing wiper refill.
  - Wiper refill is not twisted at all.
  - Wiper refill thoroughly fits in the tab on wiper blade.
  - Wiper refill is inserted from the proper direction.

#### NOTE:

When the vertebra is detached.

- Insert the vertebra (1) into the wiper blade to the same bending direction.
- If a vertebra has a notch, fit it to a protrusion inside the wiper refill.



# FRONT WIPER DRIVE ASSEMBLY


< REMOVAL AND INSTALLATION >

## FRONT WIPER DRIVE ASSEMBLY

Exploded View


INFOID:000000004965944

### REMOVAL



1. Front wiper drive assembly

### DISASSEMBLY



- |                          |                          |                      |
|--------------------------|--------------------------|----------------------|
| 1. Front wiper linkage 1 | 2. Shaft seal            | 3. Front wiper motor |
| 4. Front wiper frame     | 5. Front wiper linkage 2 |                      |

: Multi-purpose grease or an equivalent.

### Removal and Installation

INFOID:000000004965945

#### REMOVAL

1. Remove the front wiper arm. Refer to [WW-135, "Exploded View"](#).
2. Remove the cowl top cover. Refer to [EXT-25, "Exploded View"](#).
3. Remove the bolts from the front wiper drive assembly.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# FRONT WIPER DRIVE ASSEMBLY

## < REMOVAL AND INSTALLATION >

---

4. Disconnect the front wiper motor connector.
5. Remove the front wiper drive assembly from the vehicle.

## INSTALLATION

1. Install the front wiper drive assembly to the vehicle.
2. Connect the front wiper motor connector.
3. Operate the front wiper to move it to the auto stop position.
4. Install the cowl top cover. Refer to [EXT-25, "Exploded View"](#).
5. Install the front wiper arms. Refer to [WW-135, "Exploded View"](#).

## Disassembly and Assembly

INFOID:000000004965946

## DISASSEMBLY

1. Remove the front wiper linkage 1 and 2 from the front wiper drive assembly.  
**CAUTION:**  
**Never bend the linkage or damage the plastic part of the ball joint when removing the wiper linkage.**
2. Remove the front wiper motor mounting screws, and then remove the front wiper motor from the front wiper frame.

## ASSEMBLY

1. Connect the front wiper motor connector.
2. Operate the front wiper to move it to the auto stop position.
3. Disconnect the front wiper motor connector.
4. Install the front wiper motor to the front wiper frame.
5. Install the front wiper linkage 2 to the front wiper motor and the front wiper frame.
6. Install the front wiper linkage 1 to the front wiper frame.  
**CAUTION:**
  - **Never drop front wiper motor or cause it to come into contact with other parts.**
  - **Be careful for the grease condition at the front wiper motor and front wiper linkage joint (retainer). Apply Multi-purpose grease or an equivalent if necessary.**

# LIGHT & RAIN SENSOR

< REMOVAL AND INSTALLATION >

## LIGHT & RAIN SENSOR


Exploded View

INFOID:000000004965947

### CAUTION:

When the light & rain sensor is removed from windshield, the light & rain sensor cannot be re-used.

### REMOVAL



1. Light & rain sensor connector
2. Inside mirror cover (LH)
3. Inside mirror cover (RH)
4. Light & rain sensor
- A. Metal spring clip

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000004965948

#### REMOVAL

1. Remove the inside mirror cover (LH and RH).
2. Disengage the both sides of metal spring clips, and remove the light & rain sensor from the windshield.
3. Disconnect the light & rain sensor connector.

#### INSTALLATION

Install in the reverse order of removal.

### CAUTION:

- Surface of windshield should be cleaned.
- Never touch gel/adhesive of new part.
- Lock the metal spring clips and install the light & rain sensor securely.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

## WIPER AND WASHER SWITCH

< REMOVAL AND INSTALLATION >

---

### WIPER AND WASHER SWITCH

Exploded View

INFOID:000000004965949

Refer to [BCS-95. "Exploded View"](#).


# REAR WIPER ARM

< REMOVAL AND INSTALLATION >

## REAR WIPER ARM

### Exploded View

INFOID:000000004965950



- 1. Rear wiper blade
- 2. Rear wiper motor
- 3. Pivot seal
- 4. Rear wiper arm
- 5. Rear wiper arm cover

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation


INFOID:000000004965951

#### REMOVAL

1. Operate the rear wiper to the auto stop position.
2. Remove the rear wiper arm cover.
3. Remove the rear wiper arm mounting nut.
4. Remove wiper arm from the vehicle.

#### INSTALLATION

1. Clean wiper arm mount as shown in the figure to prevent nut from being loosened.
2. Operate the rear wiper motor to the auto stop position.
3. Adjust the rear wiper blade position. Refer to [WW-143, "Adjustment"](#).
4. Install the rear wiper arm by tightening the mounting nut.
5. Inject the washer fluid.
6. Operate the rear wiper to the auto stop position.
7. Check that the rear wiper blades stop at the specified position.
8. Install the rear wiper arm cover.



### Adjustment

INFOID:000000004965952

#### REAR WIPER BLADE POSITION ADJUSTMENT


Clearance between the end of back door glass and the top of wiper blade center.

# REAR WIPER ARM

## < REMOVAL AND INSTALLATION >

Standard clearance

**L : 51.5 ± 7.5 mm (2.028 ± 0.295 in)**



JPLIA1236ZZ


# REAR WIPER MOTOR

< REMOVAL AND INSTALLATION >

## REAR WIPER MOTOR

### Exploded View

INFOID:000000004965953



- |                     |                         |               |
|---------------------|-------------------------|---------------|
| 1. Rear wiper blade | 2. Rear wiper motor     | 3. Pivot seal |
| 4. Rear wiper arm   | 5. Rear wiper arm cover |               |

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000004965954

#### REMOVAL

1. Remove the rear wiper arm. Refer to [WW-143, "Removal and Installation"](#).
2. Remove the back door finisher inner. Refer to [INT-42, "Exploded View"](#).
3. Disconnect the rear wiper motor connector.
4. Remove the rear wiper motor mounting bolts.
5. Remove the rear wiper motor from the vehicle.
6. Remove the pivot seal.

#### INSTALLATION

1. Install the pivot seal.
2. Install the rear wiper motor to the vehicle.
3. Connect the rear wiper motor connector.
4. Operate the rear wiper to the auto stop position.
5. Install the back door finisher inner. Refer to [INT-42, "Exploded View"](#).
6. Install the rear wiper arm. Refer to [WW-143, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

WW


# REAR WASHER NOZZLE AND TUBE

< REMOVAL AND INSTALLATION >

## REAR WASHER NOZZLE AND TUBE

Hydraulic Layout

INFOID:000000004965955



1. Rear washer nozzle

2. Rear washer tube

3. Washer tank

△ : Clip

○ : Grommet

## Removal and Installation

INFOID:000000004965956


### REMOVAL

1. Remove the high-mounted stop lamp. Refer to [EXL-236, "Exploded View"](#).

# REAR WASHER NOZZLE AND TUBE

## < REMOVAL AND INSTALLATION >

2. Push pawl (A), and remove the rear washer nozzle (1) from the back door.
3. Disconnect the rear washer tube from the rear washer nozzle.



## INSTALLATION

Install in the reverse order of removal.


## Inspection and Adjustment

INFOID:000000004965957

## INSPECTION

### Washer Nozzle Inspection

Check that air can pass through the hose by blowing forward (toward the nozzle), and check that air cannot pass through by sucking.



## ADJUSTMENT


### Washer Nozzle Spray Position adjustment

Adjust spray positions to match the positions shown in the figure.

1 : Black printed frame line

Unit: mm (in)


Spray position	H : Height	$\phi$ : Spray position area
A	23.1 (0.91)	30 (1.18)



Insert a needle or similar object (A) into the spray opening (1) and move up/down and left/right to adjust the spray position.

### NOTE:

If wax or dust gets into the nozzle, remove wax or dust with a needle or small pin.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P


# HEADLAMP WASHER SWITCH

< REMOVAL AND INSTALLATION >

## HEADLAMP WASHER SWITCH

Exploded View

INFOID:000000006055128



1. Headlamp washer switch
  2. Instrument lower panel LH
- A: Pawl

## Removal and Installation

INFOID:000000006055129

### REMOVAL

1. Remove instrument lower panel LH.
  - A/T MODELS: Refer to [IP-15, "A/T MODELS : Removal and Installation"](#).
  - M/T MODELS: Refer to [IP-27, "M/T MODELS : Removal and Installation"](#).
2. Disengage the pawls, and then remove the headlamp washer switch from the instrument driver lower panel.

### INSTALLATION

Install in the reverse order of removal.